

	090-000-127	---		
	094-000-000	01 Standard 1 XG		
	094-000-001	02 Standard 2 XG		
	094-000-002	03 Standard GM		
	094-000-003	04 Traditional XG		
	094-000-008	09 Room XG		
	082-000-004	1 Finger Plucker		
	094-000-009	10 Room GM		
	006-000-009	12 Str Guitar Pad		
	090-000-081	12 String		
	082-000-013	12 String Atmos Pad		
	006-000-022	12 String Guitar		
	091-000-084	12 String Steel		
	082-000-010	12 String Washy		
	093-000-104	12String Folk Gitarre		
	084-000-022	12String Guitar		
	007-000-105	12-String Guitar Syn		
	084-000-007	12StringGtr Acc		
	094-000-012	13 Power Kit 1		
	094-000-013	14 Power Kit 2		
	094-000-014	15 Standard Kit 1		
	094-000-015	16 Standard Kit 2		
	094-000-016	17 Rock XG		
	094-000-017	18 Power GM		
	091-000-115	2 Violinen		
	082-000-011	24 String Guitar		
	094-000-023	24 Techno XG		
	094-000-024	25 Electro XG		
	094-000-025	26 Analog XG		
	094-000-026	27 Dance XG		
	094-000-027	28 Electro GM		

	094-000-028	29 Analog GM		
	094-000-029	30 Dance GM		
	094-000-031	32 Studio Kit		
	094-000-032	33 Jazz XG		
	094-000-033	34 Jazz GM		
	094-000-034	35 Jazz Kit		
	094-000-035	36 Brush Kit		
	094-000-036	37 Hit Kit		
	094-000-037	38 Room Kit		ExtID
	094-000-038	39 Rock Kit		
	094-000-039	40 Elektro Kit		
	094-000-040	41 Brush XG		
	094-000-041	42 Brush GM		
	094-000-043	44 Analog Kit		
	094-000-044	45 Dance Kit		
	094-000-045	46 Pop Latin Kit		
	094-000-046	47 Arabic Kit		
	094-000-047	48 Cuban Kit		
	094-000-048	49 Orchestra XG		
	094-000-049	50 Orchestra GM		
	083-000-056	5th Pulse Lead		
	091-000-043	5th Saw		
	083-000-052	5th Saw Lead		
	006-000-071	70s Piano		
	081-000-090	8 Voice Synth Horns		
	083-000-053	808 State Lead		
	072-000-064	A Classic		
	072-000-114	Aah Soloist		
	009-000-042	Aah Vocal		
	009-000-044	Aah Vocal + Mixed		
	009-000-046	Aah Vocal + Mixed Mono		
	009-000-045	Aah Vocal + Mixed+Boys		

	009-000-043	Aah Vocal More		
	084-000-066	ACC Alt Sax 3 F		
	084-000-071	ACC Alt Saxo Section		
	084-000-067	Acc Sax Section 1		
	084-000-068	Acc Sax Section 2		
	084-000-070	ACC Tenor Bostic		
	084-000-064	ACC Tenor Sax F		
	084-000-065	ACC Tenor Sax Sweet		
	084-000-004	ACC TenorSax		ExtID
	008-000-010	Acro Strings		
	009-000-047	Africa Choir 1		
	009-000-048	Africa Choir 2		
	072-000-015	Aggressor Bass		
	060-000-034	Agnus "Dei"		
	090-000-059	Akkordeon 16"		
	090-000-038	Akkordeon 2x8Ch		
	090-000-022	Akkordeon 3Ch		
	090-000-058	Akkordeon 8"		
	082-000-056	Akkordeon Bass		
	090-000-037	Akkordeon Mixed 1		
	093-000-025	Akkordeon Mixed 2		
	082-000-057	Akkordeon Russisch		
	090-000-053	Akkordeon Tango		
	082-000-058	Akkordeon Tango 2		
	093-000-028	Akkordeon+Klarinette		ExtID
	093-000-026	Akkordeon+Trp		
	093-000-027	Akkordeon+Zither		
	090-000-023	Akkordeon-Musette 1		
	090-000-064	Akkordeon-Musette 2		
	082-000-059	Akkordeon-Musette 3		
	082-000-060	Akkordeon-Musette 4		
	005-000-014	Akustic Bass		

	006-000-011	Akustic Bass		
	005-000-015	Akustic Jazz Git		
	084-000-014	AkusticBass Acc		
	084-000-032	Akustik Bass		
	090-000-034	Akustikbass 1		
	091-000-126	Akustikbass 1 Pedal		
	090-000-093	Akustikbass 2		
	090-000-094	Akustikbass 2 Pedal		
	083-000-049	Alfreds Filter Solo		
	081-000-057	All Bellz		
	005-000-002	All Steel Chords		
	100-000-028	Alpina Bandon		
	100-000-027	Alpina Bassoon		
	100-000-031	Alpina Clarinet		ExtID
	100-000-026	Alpina Live		
	100-000-029	Alpina Master		
	100-000-030	Alpina Musette		
	009-000-090	Alt Sax 1		
	090-000-077	Alt Sax 2 F		
	090-000-016	Alt Sax 2 MF		
	093-000-059	Alt Sax 3 MF		
	082-000-042	Alt Sax 4		
	091-000-125	Alt Sax Ensemble		
	007-000-062	Alt Sax Zirkus		
	007-000-065	AltSax 5		
	072-000-027	Ambient Chord		
	073-000-059	Ambient Mind		ExtID
	005-000-016	Amp Guitar		
	081-000-031	Amped Wurli		ExtID
	081-000-089	Ana Synth Brass		
	083-000-054	Analog Heaven		
	073-000-011	Analog Metal Perc		

	072-000-093	Analog Pad		ExtID
	083-000-068	Analog Sequence		
	083-000-010	Analogy Pad		
	006-000-065	Andr's Orchestra		
	072-000-109	Ano Rhodes		
	006-000-054	Anthem Brass		
	093-000-003	Applause		
	083-000-084	Applause Groß		
	081-000-077	Arail		
	072-000-086	Arctic Circle		
	072-000-050	Astral Strings		
	006-000-026	Atmo Pad		
	091-000-056	Atmosphere		
	072-000-009	Atonal Percussachap		
	072-000-088	Aurora		
	083-000-087	Auto		
	072-000-006	Auto Synth		
	073-000-081	Autotif Bass		
	073-000-126	Bad Black Bass		
	006-000-064	Ballad Piano		
	083-000-040	Band Poly Lead		
	090-000-024	Bandoneon 1		
	090-000-060	Bandoneon 2		
	090-000-061	Bandoneon 3		
	091-000-062	Banjo 1		ExtID
	084-000-027	Banjo 2		
	007-000-040	Bariton Brass		
	091-000-028	Bariton Sax 1		
	082-000-043	Bariton Sax 2		
	007-000-039	BaritonBrass+Bass		
	006-000-077	Barock Ensemble		
	083-000-059	Basic Bend Lead		

	073-000-110	Bass Of Death		
	082-000-070	Bass Slide		
	082-000-071	Bass Sweep		
	091-000-044	Bass+Lead		
	008-000-103	Bassdrum 1		
	008-000-104	Bassdrum 2		
	090-000-033	Bassgitarre 1		
	006-000-041	Bassgitarre 2		
	006-000-057	Bassgitarre 3		
	009-000-109	Bassgitarre Cool		
	009-000-110	Bassgitarre Picked		
	009-000-111	Bassgitarre Unplugged		
	083-000-035	Bassline Style Pad		
	009-000-106	Basspedal		
	009-000-105	Basspedal Perc		
	006-000-051	Beauty & Beast		
	072-000-031	Beaver Att. Formation		
	083-000-083	Beifall		
	072-000-066	Bell Tinkle Pad		
	006-000-028	Bells & Strings		
	081-000-040	Belly		
	007-000-012	Beta-DB Perc		
	072-000-023	Big Ass Pad		
	009-000-082	Big Band Ensemble 1		
	009-000-083	Big Band Ensemble 2		
	006-000-086	Big Band Swing Brass		
	072-000-013	Big Dark Mega Pad		
	073-000-037	Big Drive Lead		
	073-000-035	Big Octave Pad		
	081-000-081	Big Orchestra Hit		
	091-000-090	Big Pad		
	072-000-070	Big Pwm Strings		

	073-000-056	Big Reso Bell		
	006-000-018	Big Score		
	081-000-086	Big Timpani		
	073-000-086	Big Wave Bells		
	083-000-041	Bigger Than Life		
	072-000-104	Binder Lead		
	091-000-080	Bläser Big Band 1		
	091-000-081	Bläser Big Band 2		
	090-000-107	Bläser Big Band 3		
	090-000-108	Bläser Big Band Weich		
	090-000-014	Bläsersatz		
	084-000-075	Bläsersatz 2		
	082-000-077	Bläsersatz Scharf		
	093-000-103	Bläsersatz Shake		
	083-000-092	Blippo Loop		
	005-000-019	Blues Chord Git		
	082-000-061	Blues Harp Distorted		
	091-000-032	Bottle		
	060-000-000	Bourdon		
	073-000-120	Bouw Bass		
	091-000-049	Bowed Glass		
	061-000-027	BP Bold Ranks 1		
	061-000-028	BP Bold Ranks 2		
	073-000-107	BP Brass		
	072-000-108	BP Dreams		
	061-000-025	BP GT66		
	061-000-026	BP GTR5 Solo		
	061-000-024	BP Piston 10		
	061-000-020	BP Piston 2		
	061-000-021	BP Piston 3		
	061-000-022	BP Piston 4		
	061-000-023	BP Piston 5		

	006-000-049	Brass & Strings		
	084-000-002	Brass Acc		
	093-000-043	Brass Down Up		
	091-000-114	Brass Orchester 1		
	082-000-098	Brass Orchester 2		
	093-000-017	Brass Pad		
	006-000-037	Brass Power		
	090-000-103	Brass Sforzando		
	009-000-076	Brass Stack		
	093-000-055	BrassBass		
	073-000-083	Brassy Saw Lead		
	093-000-005	Breath Noise		
	072-000-107	Bright Brass Section		
	083-000-044	Bright Buzzer Poly		
	073-000-092	Bright Chimes		
	006-000-040	Bright Drawbars		
	083-000-031	Bright Moving Pad		
	083-000-017	Bright Sweep Pad		
	082-000-046	Brighter SaxSection 1		
	082-000-047	Brighter SaxSection 2		
	091-000-057	Brightness		
	006-000-090	Broadway		
	008-000-102	Brush		
	072-000-058	Bubble Swe		
	072-000-039	Bubble Wave Electro		
	072-000-112	Buer Bass		
	009-000-007	C7 Grand Piano		
	072-000-118	Caldera		
	081-000-016	California Grand 1		
	091-000-039	Calliope		
	073-000-025	Calorizer Pad		
	083-000-073	Cascading		

	008-000-097	Castanets		
	009-000-117	CD Naturgitarre		
	009-000-116	CD Stage Piano		
	010-000-072	CD Trompete		
	091-000-007	CD-Akkordeon		
	091-000-008	CD-Akkordeon St		
	091-000-012	CD-Cembalo		
	010-000-069	CD-Cembalo Sustain		
	007-000-000	CD-DB 13 Full		
	007-000-001	CD-DB 14 Atlantis		
	007-000-002	CD-DB 15 Atlantis		
	007-000-022	CD-DB 16 Voll		
	007-000-023	CD-DB 17 Offen		
	007-000-025	CD-DB 18 Universal		
	007-000-026	CD-DB 19 Universal		
	007-000-003	CD-DB 2/3"		
	007-000-005	CD-DB 20 Atlantis		
	007-000-011	CD-DB Jazzorgel		
	007-000-027	CD-DB Lower		
	007-000-016	CD-DB Patch 1		
	007-000-017	CD-DB Patch 2		
	007-000-009	CD-DB Perkussion 1		
	007-000-010	CD-DB Perkussion 2		
	007-000-014	CD-DB Perkussion 3		
	007-000-015	CD-DB Perkussion 4		
	007-000-018	CD-DB Perkussion 5		ExtID
	007-000-013	CD-DB Super Perc		
	010-000-000	CD-DB-01		
	010-000-001	CD-DB-02		
	010-000-002	CD-DB-03		
	010-000-003	CD-DB-04		
	010-000-004	CD-DB-05		

	010-000-005	CD-DB-06		
	010-000-006	CD-DB-07		
	010-000-007	CD-DB-08		
	010-000-008	CD-DB-09		
	010-000-009	CD-DB-10		
	010-000-010	CD-DB-11		
	010-000-011	CD-DB-12		
	091-000-014	CD-Drops		
	091-000-016	CD-English Horn		
	010-000-066	CD-E-Stage		
	091-000-009	CD-Fairlight 1		
	010-000-097	CD-Fairlight 2		
	010-000-104	CD-Fairlight 3		
	091-000-010	CD-Galaxy 1		
	010-000-096	CD-Galaxy 2		
	010-000-065	CD-Jazz Gitarre 1		
	091-000-002	CD-Jazz Gitarre 2		
	010-000-012	CD-Jazz Orgel 1		
	010-000-013	CD-Jazz Orgel 2		
	010-000-014	CD-Jazz Orgel 3		
	010-000-015	CD-Jazz Orgel 4		
	010-000-016	CD-Jazz Orgel 5		
	010-000-017	CD-Jazz Orgel 6		
	010-000-018	CD-Jazz Orgel 7		
	091-000-001	CD-JazzOrgel		
	091-000-002	CD-JazzOrgel Stereo		
	010-000-070	CD-Natur Gitarre		
	091-000-015	CD-Oboe		
	010-000-067	CD-Pfeifen 1		
	010-000-068	CD-Pfeifen 2		
	091-000-011	CD-Pfeifen 2		
	007-000-049	CD-Piano		

	010-000-063	CD-Streicher		
	091-000-004	CD-Synthebrass		
	091-000-013	CD-Theater		
	010-000-064	CD-Vibraphone		
	091-000-000	CD-Violine		
	007-000-051	CD-Xylophon		
	091-000-005	CD-Zupfbass		
	091-000-006	CD-Zupfbass Ped		
	090-000-010	Celesta		
	008-000-023	Celli		
	090-000-123	Cello		
	009-000-115	Celtic Flöte		
	090-000-112	Cembalo 1		
	006-000-046	Cembalo 2		
	081-000-045	Cembalo Hell		
	073-000-012	Century Pad		
	083-000-018	Cermonial Pad		
	008-000-005	Chamber Solo		
	008-000-006	Chamber Staccato		
	008-000-011	Chamber Strings		
	083-000-074	Chaos		
	091-000-041	Charang		
	083-000-023	Chase 4 Pad		
	072-000-028	Chaser Pad		
	091-000-040	Chiff		
	081-000-066	Chime Bells		
	006-000-043	Choir + Sinus		
	090-000-036	Chor		
	091-000-088	Chor + Bells		
	091-000-078	Chor + Solo		
	093-000-082	Chor Aah		
	081-000-076	Chor Art		

	081-000-078	Chor Attack		
	081-000-079	Chor Belltime		
	081-000-074	Chor Dark		
	081-000-070	Chor Digital-Synthe		
	090-000-042	Chor Duh		
	093-000-083	Chor Frauen Aah		
	093-000-084	Chor Frauen Ooh		
	090-000-085	Chor Gemischt		
	090-000-086	Chor Gemischt+Kinder		
	081-000-072	Chor Heaven		
	090-000-088	Chor Jazz Baah		
	090-000-092	Chor Jazz Bass		
	090-000-089	Chor Jazz Dooh		
	090-000-090	Chor Jazz Gemischt		
	090-000-091	Chor Jazz Gemischt + Bass		
	090-000-087	Chor Kinder		
	093-000-085	Chor Oper		
	081-000-075	Chor Reverse		
	081-000-080	Chor Soft Sweeper		ExtID
	081-000-071	Chor Spaced		
	090-000-125	Chor Synthe		
	073-000-021	Chorus Bells		
	006-000-031	Chorus Rhodes		
	006-000-074	Chorus Wurlitzer		
	072-000-102	Chorused E-Bass		
	072-000-032	CineIntroBass		
	008-000-026	Cinematic Strings		
	008-000-105	Claps 1		
	008-000-106	Claps 2		
	072-000-081	Classic Dance Saws		
	073-000-082	Classic og Bass		
	072-000-094	Classic Square Lead		

	008-000-008	Classic Strings 1		
	008-000-009	Classic Strings 2		
	073-000-078	Clavigue		
	081-000-042	Clavinet 2 Stereo		
	090-000-113	Clavinet 1		
	091-000-097	Clavinet 1 Stereo		
	081-000-041	Clavinet 2		
	081-000-043	Clavinet 2 Chorus		
	081-000-044	Clavinet 2 WahWah		
	006-000-067	Clean Chord Guitar		ExtID
	084-000-029	Clean Guitar		
	006-000-002	Clean Strat Acc		
	084-000-011	CleanGuitar Acc		
	072-000-005	Club Rotation		
	083-000-088	Combo Loop		
	091-000-023	Comet Gitarre		
	060-000-002	Cornet		
	090-000-039	Cosmic		
	072-000-076	Cou Pad		
	073-000-095	Couter Games		
	008-000-082	Crash Becken 1		
	008-000-083	Crash Becken 2		
	008-000-084	Crash Becken Marsch		
	008-000-085	Crash Becken Splash		
	072-000-041	Creamy Arpeggio		
	091-000-055	Crystal		
	073-000-030	Curves		
	010-000-106	D50 Pad		
	006-000-038	Dance River		
	083-000-066	Dance Sawteeth		
	072-000-085	Dance Solo		
	083-000-036	Dance Stabs Lead		

	072-000-049	Dark Bell		
	083-000-094	Dark Driver Arp		
	083-000-033	Dark Driver Lead		
	083-000-097	Dark Pulsator		
	072-000-103	Days Gone By		
	084-000-114	DB 16 1-1/3 1		
	084-000-112	DB 16 8 4 2		
	084-000-113	DB 16 8 4 2 1		
	084-000-115	DB Blues 1		
	084-000-117	DB Blues 1 Perc		
	084-000-116	DB Blues 2		
	084-000-118	DB Blues 2 Perc		
	084-000-110	DB Full 1		
	084-000-111	DB Full 2		
	084-000-119	DB Lower 1		
	093-000-075	DB Lower 1		
	084-000-120	DB Lower 2		
	093-000-076	DB Lower 2		
	072-000-083	De Sea		
	091-000-087	Deep Mistery		
	073-000-111	Detuned Stage Saws		
	073-000-026	Develish Syncer		
	090-000-021	Diatonisch 1		
	090-000-062	Diatonisch 2		
	093-000-023	Diatonisch 3		
	093-000-030	Diatonisch Chorus		
	093-000-024	Diatonisch Echo		
	093-000-029	Diatonisch Mixed		
	093-000-031	Diatonisch+Bandoneon		
	073-000-002	Digi Bell		
	072-000-053	Digi Echo Pad		
	083-000-039	Digital Theme Park		

	073-000-071	Dirty Dance Organ		
	083-000-006	Dirty Sweep Pad		
	082-000-076	Disco Bass		
	084-000-034	Disco Bass		
	073-000-036	Disto Sweep Lead		
	084-000-025	Distortion Guitar		
	084-000-013	DistortionGtr Acc		
	073-000-034	DnB Square		
	073-000-094	DnB Sub Bass		
	073-000-028	Doom+Chaos		
	006-000-095	Double Bass		
	084-000-102	Draw Perc 3rd		
	006-000-075	Drawbars Combi 1		
	006-000-076	Drawbars Combi 2		
	090-000-028	Dreamharp		
	090-000-041	Dreaming		
	073-000-106	Drug Solo		
	083-000-055	Drum n Bass		
	072-000-059	Drums Of Death		
	083-000-058	Dry Fat Pulse Solo		
	060-000-003	Duciana		
	091-000-066	Dudelsack		
	084-000-100	DuhChor		
	083-000-046	Dull Square Solo		
	009-000-040	Dum Bass kurz		
	009-000-041	Dum Bass lang		
	003-000-000	DummySound		
	006-000-034	Dwarfs March		
	010-000-071	DX-Beta Brass		
	007-000-024	DX-DB Delta		
	006-000-050	Dynamic Bells		
	081-000-035	Dyno Chorus		

	081-000-033	Dyno Stage		
	072-000-014	Ear Killer		
	091-000-059	Echo Drops		
	094-000-051	Eco Dance		
	104-000-006	Eco Dance Kit		
	094-000-052	Eco HipHop		
	104-000-007	Eco HipHop Kit		
	094-000-050	Eco Kit		
	094-000-053	Eco Latin		
	104-000-008	Eco Latin Kit		
	104-000-005	Eco Normal Kit		
	093-000-110	Effekte Allg. (ab Splitt C5)		
	093-000-111	Effekte Latin (ab C5)		
	093-000-117	Effekte Pauken (ab C5)		
	093-000-114	Effekte Sakral (ab C5)		
	093-000-115	Effekte Sonstige (ab C5)		
	093-000-011	Effekte Stimmen		
	093-000-112	Effekte Trad. (ab C5)		
	093-000-116	Effekte Vokal (ab C5)		
	093-000-113	Effekte Western (ab C5)		
	104-000-063	EffektTaster		
	093-000-097	E-Git. Strato ohne Vib.		
	007-000-042	eGitarre		
	090-000-121	E-Gitarre + Verzerrer		
	090-000-119	E-Gitarre Clean		
	005-000-000	E-Gitarre Hardrock		
	082-000-025	E-Gitarre Hardrock		
	090-000-118	E-Gitarre Muted		
	093-000-093	E-Gitarre Ricky		
	093-000-107	E-Gitarre Solid		
	090-000-078	E-Gitarre Stratocaster		
	093-000-108	E-Gitarre Telecaster		

	093-000-109	E-Gitarre WahWah		
	073-000-066	Electrhodes		
	090-000-111	Elektrik Grand 1		ExtID
	091-000-072	Elektrik Grand 2		
	081-000-010	Elektrik Grand 3		
	081-000-012	Elektrik Grand Atmos		
	081-000-011	Elektrik Grand Weich		
	081-000-023	Elektrik Rhodes		
	084-000-015	ElektrikBass Acc		
	072-000-089	Elektro Noise Crash		
	083-000-034	Elektro Perc Lead		
	072-000-069	Elektro Res Congas		
	006-000-053	Emporio		
	090-000-066	Engel		
	090-000-096	Englisch Horn		
	010-000-073	Enigma Flöte		
	009-000-080	Ensemble Brass 1		
	009-000-081	Ensemble Brass 2		
	010-000-098	Entertainer Pad 1		ExtID
	010-000-099	Entertainer Pad 2		
	010-000-100	Entertainer Pad 3		
	010-000-101	Entertainer Pad 4		
	010-000-102	Entertainer Pad 5		
	010-000-103	Entertainer Pad 6		
	090-000-003	E-Piano 1		
	091-000-099	E-Piano 2		
	091-000-101	E-Piano Bells		
	081-000-038	E-Piano Nice Tyne		
	091-000-100	E-Piano Pad		
	090-000-002	E-Piano R 1		
	091-000-094	E-Piano R 2		
	091-000-093	E-Piano R 3		ExtID

	081-000-020	E-Piano Vintage		
	009-000-114	Erhu Flöte		
	011-000-000	Erkan Gitarre 1		
	011-000-001	Erkan Gitarre 2		
	072-000-068	Ethnic Pluck Loop		
	072-000-061	Euro Chase Bass		
	091-000-029	Fagott 1		
	082-000-050	Fagott 2		
	072-000-080	Falling Star Pad		
	091-000-117	Fanfare 1		
	091-000-118	Fanfare 2		
	091-000-045	Fantasia		
	091-000-095	Fantasy E-Piano		
	082-000-062	Fat Acoustic Bass		
	072-000-029	Fat Analog Bass Slap		
	083-000-064	Fat Analog Lead		
	081-000-083	Fat Hit		
	072-000-127	Fat Sync Poly		
	005-000-009	Fender Rock Bass		
	007-000-046	Fender Strat 1		
	007-000-047	Fender Strat 2		
	007-000-048	Fender Strat Chorus		
	091-000-067	Fiddle		
	073-000-076	Filling Rattler		
	093-000-014	Filter Brass		
	073-000-046	Filter Keys		
	072-000-121	Filter Super Drivio		
	006-000-021	Final Music		
	007-000-090	Finger Bass		
	084-000-030	Finger Bass		
	082-000-066	Finger Jazz Bass		
	082-000-067	Finger P Bass		

	093-000-000	Fingerbass Ped		
	008-000-096	Fingersnaps		
	073-000-017	Firus		
	072-000-096	Fishsex		
	082-000-051	Flöte		
	082-000-052	Flöte Tremolo Fade		
	082-000-053	Flöte Tremolo Switch		
	082-000-054	Flöte Vibrato		ExtID
	009-000-005	Flügel 1 + Streicher		
	009-000-006	Flügel 1 + StreicherSolo		
	009-000-002	Flügel 1 Deckel zu		
	009-000-004	Flügel 1 Oktave		
	009-000-000	Flügel 1a		
	009-000-001	Flügel 1b		
	090-000-000	Flügel 2		
	091-000-071	Flügel 2 + Oktave		
	081-000-003	Flügel 2 Hart		
	093-000-089	Flügel 2 Klassik		
	081-000-004	Flügel 2 Konzerthalle		
	081-000-002	Flügel 2 Weich		
	090-000-109	Flügel Hell 1		
	081-000-001	Flügel Hell 2		
	081-000-000	Flügel Natural		
	090-000-045	Flügelhorn		
	060-000-004	Flute 4		
	060-000-005	Flute Celeste		
	082-000-075	FM Bass		
	081-000-036	FM Elektrik Piano		
	082-000-023	FM Jazz Gitarre		
	008-000-045	FM Mix Streicher		
	090-000-011	Frauenstimme + Effekt		
	090-000-102	Frauenstimme + Sustain		

	093-000-086	Frei-----		
	082-000-084	French Horn Section		
	006-000-020	Fresh Latin Sinus		
	082-000-069	Fretless Bass		
	084-000-033	Fretless Bass		
	084-000-017	FretlessBass Acc		
	006-000-056	Full Chorus		
	008-000-016	Full Orchester		
	008-000-007	Full Strings		
	081-000-028	Full Wurli		
	083-000-091	Funky Chap Loop		
	081-000-027	Fusion		
	072-000-095	Fuzz Melody		
	072-000-122	FuzzaFizzle Bass		
	073-000-122	Fuzzy Bass Riff		
	072-000-082	Fuzzy Chap		
	072-000-051	Fuzzy Gurgler		
	088-000-126	FX Mute		
	088-000-001	FX1 LongReverb		
	088-000-002	FX1 Short Reverb		
	088-000-000	FX1 Standard Reverb		
	088-000-031	FX2 LongReverb		
	088-000-030	FX2 Standard Reverb		
	088-000-060	FX3 Standard Chorus		
	088-000-091	FX4 Delay Mix 100		
	088-000-090	FX4 Standard Delay		ExtID
	060-000-006	Gamba		
	083-000-045	Gangsta Whine		
	060-000-008	Gedackt 16		ExtID
	060-000-007	Gedackt 8		
	081-000-021	Gentle Vintage EP		
	091-000-020	GG-AirMallet		

	091-000-019	GG-Fusion		
	091-000-022	GG-Marimba		
	007-000-041	GG-MutedGitarre		
	091-000-017	GG-Panflöte		
	091-000-021	GG-PercEcho		
	091-000-096	GG-Schalmei		
	091-000-018	GG-Synvocal		
	072-000-024	Ghost Rave		
	083-000-029	Ghost Ship Pad		
	083-000-012	Ghost Wave Pad		
	083-000-072	Glass Menagerie		
	083-000-022	Glassy Pad		
	090-000-104	Glenn Miller Sound		
	090-000-116	Glocken		
	073-000-020	Glocken Loop		
	090-000-009	Glockenspiel		
	094-000-019	GM Power Kit Dance		
	094-000-021	GM Power Kit Elektro		
	094-000-020	GM Power Kit Live		
	094-000-018	GM PowerKit Std		
	089-000-000	GM001 Acoustic Grand		
	089-000-001	GM002 Bright Grand		
	089-000-002	GM003 Electric Grand		
	089-000-003	GM004 Honky Tonk		
	089-000-004	GM005 E-Piano 1		
	089-000-005	GM006 E-Piano 2		
	089-000-006	GM007 Harpsichord		
	089-000-007	GM008 Clavinet		
	089-000-008	GM009 Celesta		
	089-000-009	GM010 Glockenspiel		
	089-000-010	GM011 Music Box		
	089-000-011	GM012 Vibraphone		

	089-000-012	GM013 Marimba		
	089-000-013	GM014 Xylophone		
	089-000-014	GM015 Tubular Bells		
	089-000-015	GM016 Dulcimer		
	089-000-016	GM017 Organ		
	089-000-017	GM018 Perc. Organ		
	089-000-018	GM019 Rock Organ		
	089-000-019	GM020 Church Organ		
	089-000-020	GM021 Reed Organ		
	089-000-021	GM022 Akkordeon		
	089-000-022	GM023 Harmonica		
	089-000-023	GM024 Tango Akkordeon		
	089-000-024	GM025 Nylon Guitar		
	089-000-025	GM026 Steel Guitar		
	089-000-026	GM027 Jazz Guitar		
	089-000-027	GM028 Electric Guitar		
	089-000-028	GM029 Muted Guitar		
	089-000-029	GM030 Overdr. Guitar		
	089-000-030	GM031 Distor. Guitar		
	089-000-031	GM032 Harm. Guitar		
	089-000-032	GM033 Acoustic Bass		
	089-000-033	GM034 Finger Bass		
	089-000-034	GM035 Picked Bass		
	089-000-035	GM036 Fretles Bass		
	089-000-036	GM037 Slap Bass 1		
	089-000-037	GM038 Slap Bass 2		
	089-000-038	GM039 Synthe Bass 1		
	089-000-039	GM040 Synthe Bass 2		
	089-000-040	GM041 Violin		ExtID
	089-000-041	GM042 Viola		
	089-000-042	GM043 Cell0		
	089-000-043	GM044 Contrabass		

	089-000-044	GM045 Tremolo Strings		
	089-000-045	GM046 Pizzicato Str.		
	089-000-046	GM047 Harp		
	089-000-047	GM048 Timpani		
	089-000-048	GM049 Strings 1		
	089-000-049	GM050 Strings 2		
	089-000-050	GM051 Synthe Str. 1		
	089-000-051	GM052 Synthe Str.2		
	089-000-052	GM053 Choir Aahs		
	089-000-053	GM054 Voice Oohs		
	089-000-054	GM055 Synthe Voice		
	089-000-055	GM056 Orchestra Hit		
	089-000-056	GM057 Trumpet		
	089-000-057	GM058 Trombone		
	089-000-058	GM059 Tuba		
	089-000-059	GM060 Muted Trp.		
	089-000-060	GM061 French Hor		
	089-000-061	GM062 Brass Sectio		
	089-000-062	GM063 Synthe Brass 1		
	089-000-063	GM064 Synthe Brass 2		
	089-000-064	GM065 Sopran Sax		
	089-000-066	GM066 Alto Sax		
	089-000-065	GM066 Tenor Sax		
	089-000-067	GM068 Baritone Sax		
	089-000-068	GM069 Oboe		
	089-000-069	GM070 English Horn		
	089-000-070	GM071 Bassoon		
	089-000-071	GM072 Clarinet		
	089-000-072	GM073 Piccolo		
	089-000-073	GM074 Flute		
	089-000-074	GM075 Recorder		
	089-000-075	GM076 Pan Flute		

	089-000-076	GM077 Blown Bottle		
	089-000-077	GM078 Shakuhachi		
	089-000-078	GM079 Whistle		
	089-000-079	GM080 Ocarina		
	089-000-080	GM081 Lead Square		
	089-000-081	GM082 Sawtooth		ExtID
	089-000-082	GM083 Calliope		
	089-000-083	GM084 Chiff		
	089-000-084	GM085 Charang		
	089-000-085	GM086 Solo Vox		
	089-000-086	GM087 5th Saw		
	089-000-087	GM088 Bass+Lead		
	089-000-088	GM089 Fantasia		
	089-000-089	GM090 Warm Pad		
	089-000-090	GM091 Polysynth		
	089-000-091	GM092 Space Vocal		
	089-000-092	GM093 Bowed Glass		
	089-000-093	GM094 Metal Pad		
	089-000-094	GM095 Halo Pad		
	089-000-095	GM096 Sweep Pad		
	089-000-096	GM097 Ice Rain		
	089-000-097	GM098 Soundtrack		
	089-000-098	GM099 Crystal		
	089-000-099	GM100 Atmosphere		
	089-000-100	GM101 Brightness		
	089-000-101	GM102 Goblins		
	089-000-102	GM103 Echo Drops		
	089-000-103	GM104 Star Theme		
	089-000-104	GM105 Sitar		
	089-000-105	GM106 Banjo		
	089-000-106	GM107 Shamisen		
	089-000-107	GM108 Koto		

	089-000-108	GM109 Kalimba		
	089-000-109	GM110 Bag Pipe		
	089-000-110	GM111 Fiddle		
	089-000-111	GM112 Shanai		
	089-000-112	GM113 Tinkle Bell		ExtID
	089-000-113	GM114 Agogo		
	089-000-114	GM115 Steel Drums		
	089-000-115	GM116 Woodblock		
	089-000-116	GM117 Taiko Drums		
	089-000-117	GM118 Melodic Tom		
	089-000-118	GM119 Synthe Drum		
	089-000-119	GM120 Reverse Cymbal		
	089-000-120	GM121 Guitar FretNoise		
	089-000-121	GM122 Breath Noise		
	089-000-122	GM123 Seashore		
	089-000-123	GM124 Bird Tweet		
	089-000-124	GM125 Telephone		
	089-000-125	GM126 Helicopter		
	089-000-126	GM127 Applause		
	089-000-127	GM128 Gunshot		
	091-000-058	Goblins		
	072-000-001	Good Vibes		
	072-000-116	Grain Brain		
	006-000-096	Grand Chorus		
	006-000-052	Grand Final		
	006-000-015	Grand Movie Score		
	084-000-105	Grand Piano		
	006-000-045	Grand Theatre		
	005-000-011	Green Rock Guitar		
	060-000-035	Gregorian Choir		
	093-000-006	Guitar Fretless		
	006-000-030	Gypsy Percussion		

	090-000-044	Hackbrett		
	072-000-022	Hairy Bass		
	091-000-051	Halo Pad		
	090-000-124	Harfe		
	006-000-059	Harpsichord		
	081-000-046	Harpsichord + Oktave		
	090-000-046	Hawaii-Gitarre		
	072-000-004	Heart Solo		
	007-000-004	Helios-DB Celesta		
	007-000-028	Helios-DB Lower		
	007-000-021	Helios-DB Perkussion		
	082-000-088	Helle Legato Streicher		
	082-000-089	Helle Streicher Att.		
	073-000-003	Hi Tone Bell		
	006-000-084	High Strings		
	006-000-058	Higher & Higher		
	008-000-088	Hihat Pedal		
	084-000-008	HiStringGtr Acc		
	007-000-112	Hit		
	081-000-084	Hit Cluster		
	081-000-062	Hold Bell Layer		
	073-000-014	Hollow Bass		
	006-000-029	Hollywood Strings		
	008-000-027	Hollywood Strings		
	006-000-069	Honky Man		
	090-000-110	Honky Tonk 2		
	081-000-008	Honky Tonk Hell		
	009-000-003	HonkyTonk 1		
	090-000-097	Horn Ensemble		
	090-000-098	Horn Section Swell		
	090-000-099	Horn Section Warm		
	090-000-100	Horn Solo		

	073-000-009	Horny		
	072-000-100	HP Dirty Swe		
	072-000-098	HP Dirty Swe Arp		
	081-000-091	HP Synth Brass		
	072-000-091	HS Bassline		
	093-000-008	Hubschrauber		
	006-000-097	Huge Orchestra		
	073-000-047	Humble Stance		
	081-000-099	Hybrid Brass Section		
	082-000-085	Hybrid Horn Section		
	081-000-032	Hybrid Stage Piano		
	082-000-082	Hybrid Staps		
	073-000-000	Hyper Sweep Pad		
	073-000-029	Hyper vs P		
	072-000-008	Ice Cold Swe		
	091-000-053	Ice Rain		
	006-000-082	Impact House Piano		
	006-000-072	Impact Orchestra		
	083-000-077	In Need Of Oil		
	073-000-055	Industrialised		
	073-000-127	Init Patch		
	073-000-054	Interval og		
	073-000-074	Intro HighPass Pad		
	081-000-085	Italo Hit		
	073-000-077	Itchy Saws		
	072-000-119	J Drums 1		
	073-000-073	J Drums 2		
	005-000-018	Jazz Git 2		
	093-000-039	Jazz Git. ->Bläser		
	005-000-010	Jazz Guitar		
	006-000-100	Jazz Guitar		
	084-000-024	Jazz Guitar		

	006-000-102	Jazz Piano		
	093-000-035	Jazz Piano Split		
	093-000-036	Jazz SaxoBrass Split		
	093-000-020	Jazz-Flöte 1		
	090-000-018	Jazz-Flöte 2		
	090-000-005	Jazz-Gitarre		
	093-000-090	Jazz-Gitarre Django		
	093-000-037	Jazzgitarre Split		
	073-000-005	Jet Pad		
	008-000-095	Jingle Bells		
	072-000-074	Joan's Lead		
	073-000-087	Journey To Pluto		
	073-000-125	Juicy PWM Poly		
	072-000-071	Jupiter Arp		
	073-000-117	Jupiter Keys		
	072-000-072	Jupiter Thu		
	006-000-027	Just Bells		
	091-000-065	Kalimba		
	091-000-082	Karibik		
	072-000-125	Karma Lead		
	090-000-032	Kesselpauke 1		
	008-000-072	Kesselpauke 2		
	060-000-001	Klarinette		
	090-000-017	Klarinette 1		
	093-000-040	Klarinette 2		
	082-000-048	Klarinette Loose		
	093-000-079	Klarinette Swing		
	082-000-049	Klarinette Thin		
	009-000-103	Klarinette Weich		
	081-000-005	Klavier Atmos		
	081-000-017	Klavier Heaven		
	081-000-006	Klavier House		

	081-000-015	Klavier LA Hart		
	081-000-014	Klavier LA Weich		
	081-000-007	Klavier Old Upright		
	081-000-009	Klavier Phaser		
	081-000-013	Klavier Resonance		
	081-000-018	Klavier Steele Hammer		
	091-000-092	Kontrabass		
	093-000-094	Kontrabass Ensemble		
	009-000-030	Konzert Gitarre		
	009-000-031	Konzert Gitarre Slide		
	091-000-064	Koto		
	073-000-093	Kraftworks		
	012-000-004	KW Flöte		
	012-000-022	KW 12String Gitarre		
	012-000-000	KW Akkordeon		
	012-000-009	KW BaritonSax		
	012-000-015	KW Bläser 1		
	012-000-016	KW Bläser 2		ExtID
	012-000-027	KW CD-Bass		
	012-000-023	KW Django Gitarre		
	012-000-003	KW E-Flöte		
	012-000-001	KW Franz. Akkordeon		
	012-000-020	KW Geige		
	012-000-050	KW Helios		
	012-000-066	KW Helios ACC Guitar		
	012-000-065	KW Helios Bass		
	012-000-067	KW Helios Brass Miller DB		
	012-000-055	KW Helios Brass Tico		
	012-000-064	KW Helios DB Bells		
	012-000-052	KW Helios DB BellsChorus		
	012-000-043	KW Helios DB Lead 1		
	012-000-044	KW Helios DB Lead 2		

	012-000-061	KW Helios Dry Strings		
	012-000-069	KW Helios HonkyTonk		
	012-000-046	KW Helios MellowMiller DB		
	012-000-048	KW Helios Miller DB		
	012-000-063	KW Helios Miller MtTrumpet		
	012-000-073	KW Helios Miller Trombone DB		
	012-000-049	KW Helios Miller Voll DB		
	012-000-056	KW Helios MillerHorn		
	012-000-047	KW Helios MillerKlarinette		ExtID
	012-000-058	KW Helios MillerReeds		
	012-000-057	KW Helios MillerSax		
	012-000-070	KW Helios MoonFlugel		
	012-000-072	KW Helios Moonlight Miller		
	012-000-051	KW Helios Perkussion		
	012-000-068	KW Helios PianoStrings		
	012-000-059	KW Helios Streicher ft8		
	012-000-060	KW Helios StreicherBlaster		
	012-000-062	KW Helios Str-Harpsichord		
	012-000-071	KW Helios Sweet Miller DB		
	012-000-045	KW Helios Tico DB LM		
	012-000-054	KW Helios Tico Wah		
	012-000-053	KW Helios Tico WahWah		
	012-000-014	KW Horn		
	012-000-039	KW Jimmy 1		
	012-000-040	KW Jimmy 2		
	012-000-010	KW Klarinette		
	012-000-036	KW LM Orgel 1		
	012-000-037	KW LM Orgel 2		
	012-000-038	KW LM Orgel 3		
	012-000-017	KW Mantovani Str.		
	012-000-013	KW Muted Trompete		
	012-000-021	KW Orchester		

	012-000-006	KW Panflöte		
	012-000-041	KW Perk Orgel 1		
	012-000-042	KW Perk Orgel 2		
	012-000-028	KW Piano 1		
	012-000-029	KW Piano 2		
	012-000-005	KW Piccolo		
	012-000-025	KW Plek. Gitarre		
	012-000-012	KW Posaune		
	012-000-034	KW Reed Orgel 1		
	012-000-035	KW Reed Orgel 2		
	012-000-026	KW RHG Pizzikato		
	012-000-024	KW Rhythmus Gitarre		
	012-000-007	KW Saxophone		
	012-000-002	KW Soprano		
	012-000-030	KW Steeldrums		
	012-000-019	KW Streicher		
	012-000-018	KW Symphonische Str.		
	012-000-008	KW TenorSax		
	012-000-011	KW Trompete		
	012-000-031	KW Zugriegel 1		
	012-000-032	KW Zugriegel 2		
	012-000-033	KW Zugriegel 3		
	083-000-086	Lachen Groß		
	083-000-085	Lachen Klein		
	084-000-001	Large Strings Acc		
	073-000-038	Late Synbrass		
	082-000-031	Lead Atmos + Pad		
	082-000-028	Lead Gitarre		
	082-000-030	Lead Gitarre Licks		
	082-000-029	Lead Gitarre Wah		
	091-000-037	Lead Square		
	008-000-025	Legato + Chamber Solo		

	008-000-024	Legato + Chamber Str.		
	082-000-095	Legato Str.->Pizz Wheel		
	008-000-000	Legato Streicher 1		
	008-000-022	Legato Streicher 2		
	082-000-094	Legato->Tremolo Wheel		
	073-000-088	LFO Bass		
	073-000-085	LFO ve		
	006-000-055	Living Bell Strings		
	072-000-092	LoFi Sinus		
	081-000-082	Long Orchestra Hit		
	083-000-014	Long Sweep Pad		
	083-000-027	Lost Souls Pad		
	073-000-043	Low Hangin Mumma		
	072-000-056	Lunar Eclipse		
	008-000-028	Lush Strings		
	072-000-079	M Drums 1		
	073-000-049	M Drums 2		
	090-000-082	Mandoline 1		
	006-000-036	Mandoline 2		
	007-000-045	Mandoline Sustain		
	090-000-083	Mandolinen-Orchester		
	006-000-032	Marc Strings		
	006-000-066	Marching Band		
	007-000-054	Marimba		
	081-000-051	Marimba 1		
	090-000-115	Marimba 2		
	081-000-052	Marimba Bass		
	093-000-102	Marimba Repeat		
	073-000-022	Mars n Venus		
	090-000-030	Matrix		
	073-000-112	M-Bassy		
	081-000-087	Medium Timpani		

	093-000-010	Meeresrauschen		
	083-000-011	Mega Pad		
	072-000-090	Mega Swe Pad		
	006-000-042	Megasinus		
	081-000-061	Melody Bells		
	072-000-065	Melody Maker		ExtID
	100-000-069	Mengascini 1		
	100-000-078	Mengascini 10		
	100-000-079	Mengascini 11		
	100-000-070	Mengascini 2		
	100-000-071	Mengascini 3		
	100-000-072	Mengascini 4		ExtID
	100-000-073	Mengascini 5		
	100-000-074	Mengascini 6		
	100-000-075	Mengascini 7		
	100-000-076	Mengascini 8		
	100-000-077	Mengascini 9		
	100-000-068	Mengascini Live		
	072-000-113	Mery Pad		
	073-000-124	Metal BandBass		
	091-000-050	Metal Pad		
	081-000-039	Metal Tyne		
	072-000-021	Metalliga		
	083-000-008	Milky Way Pad 1		
	072-000-048	Milky Way Pad 2		
	084-000-069	Miller Sax		
	006-000-004	Miller Section		
	072-000-075	Mind Machine		
	073-000-045	Miss HipHop		
	006-000-080	Miss Streisand		
	060-000-010	Mixture 2		
	060-000-011	Mixture 3		

	060-000-012	Mixture 4		
	060-000-013	Mixture 5		
	060-000-009	Mixture1		
	008-000-042	MKS Strings		
	083-000-069	Modern Lead		
	072-000-045	Monster Rave		
	008-000-041	Moog Strings		
	100-000-020	Morino Accord		
	100-000-015	Morino Bandoneon		
	100-000-013	Morino Bassoon		
	100-000-022	Morino Celeste		
	100-000-024	Morino Clarin		
	100-000-016	Morino Harmon		
	100-000-025	Morino Jazz Special		
	100-000-019	Morino Master		
	100-000-021	Morino Musette		
	100-000-023	Morino Oboe		
	100-000-017	Morino Organ		
	100-000-014	Morino V. Cello		
	100-000-012	Morino V. Live		
	100-000-018	Morino Violin		
	008-000-037	Movie Brass		
	008-000-038	Movie Brass Artikulation		
	008-000-029	Movie Brass Orchestra		
	008-000-060	Movie Hit 1		
	008-000-061	Movie Hit 2		
	008-000-062	Movie Hit Special		ExtID
	008-000-031	Movie Horns		
	008-000-030	Movie Strings+Vocals		
	008-000-032	Movie Zimmer Horns 1		
	008-000-033	Movie Zimmer Horns 2		
	006-000-048	Mozart Orchestra		

	009-000-086	Mr. James Brass		
	006-000-062	Mr. Trombone		
	073-000-119	Muckiphonic PulsStr.		
	090-000-026	Mundharmonika		
	093-000-078	Mundharmonika Blues		
	100-000-045	Musette 2Voix 1		
	100-000-054	Musette 2Voix 10		
	100-000-055	Musette 2Voix 11		
	100-000-046	Musette 2Voix 2		
	100-000-047	Musette 2Voix 3		
	100-000-048	Musette 2Voix 4		
	100-000-049	Musette 2Voix 5		
	100-000-050	Musette 2Voix 6		
	100-000-051	Musette 2Voix 7		
	100-000-052	Musette 2Voix 8		
	100-000-053	Musette 2Voix 9		
	100-000-044	Musette 2Voix Live		
	100-000-057	Musette 3Voix 1		
	100-000-066	Musette 3Voix 10		
	100-000-067	Musette 3Voix 11		
	100-000-058	Musette 3Voix 2		
	100-000-059	Musette 3Voix 3		
	100-000-060	Musette 3Voix 4		
	100-000-061	Musette 3Voix 5		
	100-000-062	Musette 3Voix 6		
	100-000-063	Musette 3Voix 7		
	100-000-064	Musette 3Voix 8		
	100-000-065	Musette 3Voix 9		
	100-000-056	Musette 3Voix Live		
	100-000-033	Musette American 1		
	100-000-042	Musette American 10		
	100-000-043	Musette American 11		

	100-000-034	Musette American 2		
	100-000-035	Musette American 3		
	100-000-036	Musette American 4		
	100-000-037	Musette American 5		
	100-000-038	Musette American 6		
	100-000-039	Musette American 7		
	100-000-040	Musette American 8		
	100-000-041	Musette American 9		
	100-000-032	Musette Live		
	090-000-114	Musicbox		
	006-000-005	Muted Guitar		
	084-000-023	Muted Guitar		
	093-000-038	Muted Trp ->Bläser		
	ExtID	Name0		
	ExtID	Name0		
	ExtID	Name0		
	060-000-014	Nasard		
	081-000-047	Nastichord		
	006-000-088	Nasty Synth		
	009-000-113	Native American Flöte		
	090-000-004	Naturgitarre 1		
	090-000-079	Naturgitarre 2		
	082-000-000	Naturgitarre Nylon Finger		
	093-000-099	Naturgitarre Slide		
	073-000-070	Nightmare Lead		
	073-000-075	Noise Zap Arp		
	082-000-027	Nu Metal Stack		
	072-000-047	Numan Strings		
	082-000-009	Nylon + Steel Hybrid		
	082-000-001	Nylon Finger & Harm.		
	082-000-003	Nylon Finger Hell		
	007-000-044	Nylon Gitarre Acc		

	082-000-005	Nylon Pick		
	084-000-020	Nylon String +1		
	082-000-002	Nylon1+Harmonic+Ham.		
	082-000-006	Nylon2+Harmonics+Ham.		
	084-000-005	NylonGuitar Acc		
	090-000-029	Oberheim		
	081-000-092	Oberhype Brass		
	073-000-084	OBlake		
	060-000-015	Oboe		
	090-000-020	Oboe		ExtID
	091-000-112	Oboe+Fagott+Streicher		
	091-000-036	Ocarina		
	072-000-003	Oceanarium		
	060-000-016	Octave		
	073-000-097	Old School Tune		
	006-000-010	Ooh Backings		
	090-000-040	Orchester + Pauke		
	091-000-113	Orchester Barock		
	008-000-051	Orchester Bass		
	008-000-052	Orchester Glockenspiel		
	008-000-039	Orchester Harfe		
	008-000-036	Orchester Oboe		
	008-000-070	Orchester Pauke 1		
	008-000-071	Orchester Pauke 2		
	008-000-080	Orchester Piat 1		
	008-000-081	Orchester Piat 2		
	082-000-099	Orchester Tutti		
	008-000-034	Orchester Woodwinds 1		
	008-000-035	Orchester Woodwinds 2		
	091-000-026	Orchesterhit		
	006-000-079	Orchestra & Piano		
	006-000-094	Orchestra Bass		

	006-000-047	Orchestra Timpani		
	006-000-024	Orchestral Brass		
	006-000-070	Orchestral Harp		
	084-000-104	Organ		
	073-000-062	Organic Lead		
	073-000-102	OrgaThu Bass		
	093-000-044	Orgel Universal		
	083-000-071	OscSync Solo		
	005-000-021	Other 12 String		
	072-000-016	Outback		
	084-000-012	OverdriveGtr Acc		
	090-000-120	Overdriven Guitar		
	073-000-052	Overtone Solo Lead		
	073-000-113	P Vox Bell		
	083-000-090	Packman Loop		
	081-000-024	Paddy Roads		
	091-000-077	Panflöte + Synthe		
	090-000-019	Panflöte 1		
	093-000-018	Panflöte 2		
	009-000-097	Panflöte Horea		
	009-000-098	Panflöte Horea Delay		
	009-000-099	Panflöte Horea Soft 1		
	009-000-100	Panflöte Horea Soft 2		
	009-000-101	Panflöte Horea Soft 3		
	007-000-063	Panflöte Vibrato		
	007-000-064	Panflöte Wild		
	091-000-086	Paradise		
	072-000-106	Paranoia		
	093-000-100	Pedal Steel Gitarre		
	093-000-101	Pedal Steel Slide Gitarre		
	090-000-035	Pedalbass 1		
	090-000-063	Pedalbass 2		

	091-000-126	Pedalbass 3		
	093-000-060	Pedalbass+Kesselpauke		
	093-000-063	Pedalbass+Orchester		
	093-000-065	Pedalbass+Sinus		
	093-000-061	Pedalbass+Streicher 1		
	093-000-062	Pedalbass+Streicher 2		
	093-000-064	Pedalbass+Tuba		
	083-000-095	Per Chime Arpeggio		
	084-000-103	Perc Organ		
	006-000-081	Percussion Solo		
	006-000-060	Percussive & Strings		
	006-000-073	Percussive Lead		
	073-000-001	Percy RezNoiseInator		
	093-000-045	Perk. Orgel Universal		
	091-000-035	Pfeifen		
	073-000-063	Phased Leader		
	083-000-070	Phaser Dance		ExtID
	073-000-007	Phaser HP Sequencer		
	072-000-101	Phaser Sequence		
	081-000-048	Phaserichord		
	073-000-098	Phat Pwm Bass		
	073-000-016	Phat Solo Sync		
	091-000-073	Piano + Chor		
	090-000-095	Piano + DreamSound		
	091-000-091	Piano + Streicher		
	006-000-007	Piano Pad		ExtID
	091-000-030	Piccolo Flöte 1		
	082-000-055	Piccolo Flöte 2		
	082-000-064	Pick Bass 1		
	082-000-065	Pick Bass 2		
	084-000-016	PickBass Acc		
	007-000-089	Picked Bass		

	084-000-031	Picked Bass		
	093-000-001	Pickedbass Pedal		
	073-000-060	Pinhead Arp		
	006-000-063	Pirates Score		
	083-000-063	Pitch EG Lead		
	093-000-022	Pizzikato 1 Ensemble		
	090-000-050	Pizzikato 1 Solo		
	082-000-092	Pizzikato 2		
	008-000-004	Pizzikato Strings		
	060-000-018	Plenum 1		
	060-000-019	Plenum 2		
	060-000-020	Plenum 3		
	060-000-021	Plenum 4		
	083-000-065	Poly Slap		
	072-000-018	Polyrhythm Pad		
	090-000-051	Polysynth		
	084-000-072	Posaune		ExtID
	009-000-070	Posaune 1		
	009-000-072	Posaune 1 Hell		
	009-000-071	Posaune 1 Soft		
	090-000-013	Posaune 2		
	091-000-076	Posaune 2 Jazz		
	090-000-052	Posaune 2 Weich		
	082-000-037	Posaune 3		
	082-000-038	Posaune 4 Weich		
	084-000-073	Posaune Acc		
	082-000-039	Posaune Klein		
	009-000-073	Posaunen Ensemble 1		
	090-000-105	Posaunen Ensemble 2		
	084-000-074	Posaunen Ensemble Acc		
	005-000-012	Power Chords		
	005-000-017	Power Chords 2		

	104-000-002	Power Dance		
	104-000-004	Power Elektro		
	104-000-001	Power Kit		
	104-000-003	Power Live		
	072-000-097	Power Squared		
	083-000-019	Power Swell Pad		
	081-000-065	Pretty Bells		
	060-000-023	Prinzipal 16		
	060-000-022	Prinzipal 8		
	073-000-121	Proph 2		
	073-000-091	Prophet Arp		
	083-000-057	Pulse Lead		
	083-000-013	Pulsing Wave Pad		
	081-000-094	Punch Brass		
	082-000-063	Punchy Acoustic Bass		
	073-000-068	Punchy Sequence		
	073-000-104	Pure Wet Fat		
	083-000-098	Pypa Arpeggio		
	073-000-006	Quad Saw Solo		
	072-000-105	Quaeko		
	093-000-080	Querflöte 1		
	009-000-104	Querflöte 2		
	060-000-024	Quint 2 2-3		
	083-000-078	R2D2		
	072-000-025	Rave Signal Squares		ExtID
	083-000-037	Rave Synth Lead		
	072-000-019	Real Analog Kit		
	082-000-078	Real Brass Section 1		
	082-000-079	Real Brass Section 2		
	091-000-031	Recorder		
	090-000-117	Reed Organ		
	006-000-016	Refrain Sinus		

	060-000-025	Regal 16		
	072-000-040	Release Shatter Pad		
	073-000-101	Repeat Bass		
	073-000-057	Reso Gater		
	073-000-004	Reso Smack Bass		
	083-000-016	Retro Pad		
	006-000-008	Rhodes Pad		
	084-000-099	Rhythm Synthe		
	083-000-025	Rhythmic Pad		
	073-000-096	Rich Square Bell		
	072-000-110	Rich Sync Pad		
	072-000-063	Rich Wave Bells Pad		
	008-000-086	Ride Becken 1		
	008-000-087	Ride Becken 2		
	073-000-027	Ringtone Lead		
	083-000-030	Rising Star Pad		ExtID
	084-000-101	Rock Organ		
	093-000-046	Rock Orgel Universal		
	006-000-033	Rock Symphony		
	060-000-026	Rohrflöte		
	060-000-017	Rohrgedackt		
	090-000-027	Rolandy		
	006-000-017	Romance Chor		
	072-000-057	Roundabout		
	072-000-042	Rubber Reso Bass		
	072-000-126	S&H Noise		
	072-000-038	S+H Worlds		
	083-000-009	S+H Worlds Pad		
	072-000-060	Sad tion Pad		
	093-000-051	Sakral Mixed + Chor		
	093-000-049	Sakral Mixed 1		
	093-000-048	Sakral Mixed 2		

	093-000-047	Sakral Mixed 3		
	090-000-048	Sakral Prinzipal		
	090-000-049	Sakral Rohrflöte		
	093-000-050	Sakral Tutti + Chor		
	090-000-047	Sakral Tutti 1		
	093-000-052	Sakral Tutti 2		
	072-000-046	Salthar		
	072-000-044	Sandy Solo		
	073-000-015	Saw Pad Sweep		
	083-000-003	Saw Pad Sweep		
	073-000-115	SawPluck		
	091-000-038	Sawtooth		
	093-000-034	Sax + Orgel		
	093-000-032	Sax -> Brass 16		
	093-000-033	Sax -> Brass 8		
	006-000-085	Sax Eloise		
	090-000-071	Sax Ensemble 1 MF		
	091-000-079	Sax Ensemble 2 F		
	005-000-013	Sax Section 3		
	009-000-075	Sax Stack		
	006-000-001	Schlager Bells		
	081-000-088	Schlaginstrumente Orch.		
	093-000-007	Schuss		
	100-000-080	Schweizer Örgli		
	083-000-081	SciFi LFO FX		
	006-000-023	Score Strings		
	083-000-061	Screamer Lead 1		
	083-000-062	Screamer Lead 2		
	073-000-089	Self Oscillator		
	093-000-015	Seq Brass		
	083-000-093	Sequeaker Loop		
	006-000-087	Sexy Sax		

	009-000-119	SGP150 Bassgitarre		
	009-000-117	SGP150 Pedalbass		
	009-000-120	SGP150 Stringbass		
	082-000-073	SH Bass		
	091-000-033	Shakuhachi 1		
	091-000-034	Shakuhachi 1 Effekt		
	091-000-063	Shamisen		
	091-000-068	Shanai		
	009-000-112	Shehnai Oboe		
	083-000-043	Shooting Stars		
	006-000-099	Short Bells		
	073-000-023	Sile Saw Arpeggio		
	073-000-123	Silky Synth Orchestra		
	073-000-061	Single Osc Bass		
	006-000-006	Sinus Galaxy		
	091-000-061	Sitar		
	083-000-024	Sizzle 2 Pad		
	082-000-068	Slap Bass		
	084-000-035	Slap Bass		
	083-000-032	Slave Camp Pad		
	073-000-090	Smacky PWM		
	091-000-047	Small Brass		
	082-000-080	Small Brass Section		
	084-000-000	Small Strings Acc		
	091-000-098	Smooth E-Piano		
	006-000-089	Smooth Theatre		
	008-000-100	Snare 1		
	008-000-101	Snare 2		
	072-000-011	Soft Ambi Swes		
	072-000-099	Soft Bell Mallets		
	081-000-067	Soft Chimey Bells		
	083-000-021	Soft Groove Pad		

	081-000-095	Soft Res Brass		
	072-000-123	Soft Rotor Sparkle Pad		
	082-000-044	Soft SaxSection 1		
	082-000-045	Soft SaxSection 2		
	073-000-053	Soft Super Saw		
	083-000-004	Soft Super Saw Pad		
	072-000-077	Soft Sweer Rlay		
	073-000-100	Soft Synth Brass		
	081-000-022	Soft Vintage EP		
	083-000-002	Softly Pad		
	072-000-033	Softly Softly Pad		
	084-000-021	Solid Clean		
	084-000-026	Solid Wah Wah		
	084-000-009	SolidGuitar1 Acc		
	084-000-010	SolidGuitar2 Acc		
	008-000-040	Solina Strings		
	008-000-046	Solina Violin		
	008-000-047	Solina ViolinViola		
	008-000-048	Solina ViolinViola+Bass		
	008-000-049	Solina Voll		
	009-000-049	Solist Choir 1		
	009-000-050	Solist Choir 2		
	008-000-019	Solo Strings		
	008-000-021	Solo Strings Lang		
	008-000-020	Solo Strings Vibrato		
	006-000-098	Solo Violin		
	091-000-042	Solo Vox		
	083-000-047	Soloing Lead		
	009-000-054	Sopran Gruppe		
	090-000-057	Sopran Sax 1		
	091-000-123	Sopran Sax 2		
	091-000-124	Sopran Sax Dream		

	009-000-053	Sopran Solo		
	008-000-012	Sordino Strings		
	082-000-081	Soul Section Loose		
	091-000-054	Soundtrack		
	073-000-018	Space Phase		
	072-000-043	Space Rescue Mission		
	091-000-048	Space Vocal		
	093-000-106	Spanische Gitarre		
	081-000-069	Special Bells Pad		
	081-000-019	Spectral EP		
	083-000-099	Speech Sequenzer		
	072-000-073	Square & Hold Pad		
	073-000-080	Square Bells		
	072-000-124	Square Bend Lead		ExtID
	073-000-039	Square Dance		
	083-000-060	Square Lead		
	073-000-099	Square Sync Solo		
	082-000-008	St.String+Harmonics		
	006-000-092	Staccato Chor		
	008-000-015	Staccato Orch. Perc		
	008-000-014	Staccato Orchester		ExtID
	008-000-017	Staccato Str. Marcando		
	008-000-018	Staccato Strings		
	091-000-060	Star Theme		
	083-000-020	Stardust Pad		
	005-000-001	Steel Chords Velo		
	005-000-007	Steel Git Chords 5+		
	005-000-008	Steel Git Chords DIM		
	005-000-004	Steel Git Chords MIN		
	005-000-003	Steel Git Chords MJ		
	005-000-005	Steel Git Chords MJ7		
	005-000-006	Steel Git Chords SUS		

	091-000-083	Steel Gitarre 1		
	093-000-105	Steel Gitarre 2		
	084-000-019	Steel String +1		
	082-000-007	Steel String Gitarre		
	084-000-028	Steel+Body		
	091-000-070	Steeldrum 1		
	081-000-055	Steeldrum 2		
	081-000-056	Steeldrums Hell		
	084-000-006	SteelGuitar Acc		
	082-000-012	SteelString + Atmos Pad		
	007-000-043	Stereo Gitarre Acc		
	073-000-013	Stereo Sync Arp		
	007-000-050	Stereo Xylophon		
	006-000-014	Stevie's Harp		
	008-000-050	Str. Ensemble Legato		
	093-000-096	Str. KammerOrch.		
	091-000-109	Str. Violinen Attack		
	090-000-043	Str.Attack Bogen		
	082-000-016	Strat Chorus		
	082-000-014	Strat Clean		
	082-000-024	Strat Glam		
	082-000-026	Strat Grunge		
	082-000-019	Strat Harmonics		
	082-000-020	Strat Muted Velo		
	082-000-021	Strat Muted Wah		
	082-000-018	Strat Tremolo		ExtID
	082-000-017	Strat Wah		
	082-000-015	Strat+Harmonics+Ham.		
	084-000-018	Stratocaster +1		
	091-000-089	Streicher + Bells		
	091-000-104	Streicher + Chor		
	091-000-106	Streicher + Harfe		

	082-000-097	Streicher + Horns		
	091-000-111	Streicher + Horns		
	090-000-007	Streicher Attack		
	091-000-102	Streicher Mantovani		
	082-000-093	Streicher Marcato		
	093-000-081	Streicher Orchester		
	090-000-006	Streicher Orgel		
	091-000-107	Streicher Pizzikato		
	091-000-103	Streicher Sustain		
	091-000-105	Streicher Tremolo 1		
	091-000-108	Streicher Violinen		
	008-000-001	Strings 1		
	008-000-002	Strings 2		
	093-000-021	Strings Velocity Att		
	073-000-010	Stutter Pad		
	073-000-024	Sub Bass Fattener		
	083-000-096	Sub Metal Arpeggio		
	072-000-026	Sundown		
	083-000-048	Super Mini Lead		
	060-000-027	Super Oktave		
	083-000-038	Super Synth Lead		
	073-000-019	SuperFizzy StringSynth		
	100-000-001	Supita 1		
	100-000-010	Supita 10		
	100-000-011	Supita 11		
	100-000-002	Supita 2		
	100-000-003	Supita 3		
	100-000-004	Supita 4		
	100-000-005	Supita 5		
	100-000-006	Supita 6		
	100-000-007	Supita 7		
	100-000-008	Supita 8		

	100-000-009	Supita 9		
	100-000-000	Supita Live		
	009-000-008	S-Way Grand Piano		
	091-000-052	Sweep Pad		
	083-000-001	Sweeping Pad + Bells		
	073-000-067	Sweeping Worlds		
	073-000-103	Sweepy Pulse Lead		ExtID
	093-000-019	Sweet Clarinet		
	081-000-037	Sweet EP		
	007-000-066	Sweet Saxophon		
	073-000-051	Sweet Square Bell		
	073-000-008	Swirling Sync Keys		
	083-000-015	Swoosh Pad		
	008-000-013	Symphonie Strings		
	082-000-074	Syn Bass		
	073-000-050	Sync Sweep		
	083-000-042	Syncerator		
	072-000-055	Synchronas		
	010-000-105	Syn-Fair-Light		
	007-000-108	SynLeader		
	006-000-003	Synth Bass		
	081-000-096	Synth Brass Pad		
	081-000-034	Synth Wurli		
	084-000-036	Synthe Bass		
	090-000-031	Synthe Brass 1		
	081-000-093	Synthe Brass 1 Weich		
	093-000-012	Synthe Brass 2		
	081-000-098	Synthe Brass 2 Weich		
	093-000-013	Synthe Brass 3		
	081-000-097	Synthe Brass 4		
	093-000-057	Synthe Drum		
	082-000-022	Synthe Gitarre		

	091-000-024	Synthe Streicher 1		ExtID
	091-000-025	Synthe Streicher 2		
	084-000-106	Synthe Strings		
	093-000-002	Synthebass Ped		
	007-000-111	Synthebrass		
	008-000-093	Tambourin 1		
	008-000-094	Tambourin 2		
	072-000-035	Tech Siren		
	072-000-115	Techno Attack		
	093-000-009	Telefon		
	009-000-052	Tenor Gruppe		
	009-000-095	Tenor Sax 1		
	009-000-096	Tenor Sax 2		
	090-000-076	Tenor Sax 3 Bostic		
	090-000-067	Tenor Sax 3 Forte		
	090-000-015	Tenor Sax 3 Weich		
	007-000-058	Tenor Sax 4		
	082-000-041	Tenor Sax 5		
	007-000-059	Tenor Sax CD		
	093-000-091	Tenor Sax Live		
	093-000-077	Tenor Sax Live Legato		
	091-000-122	Tenor Sax Rock		
	009-000-102	Tenor Sax Section		
	007-000-061	Tenor Sax Smooth		
	091-000-121	Tenor Sax Sweet		
	007-000-060	Tenor Sax Zirkus		
	009-000-051	Tenor Solo		
	083-000-076	Tension		
	060-000-028	Terts		
	009-000-127	Test Sound		ExtID
	061-000-000	TH Barton Full		
	061-000-001	TH Barton Melo 1		

	061-000-002	TH Barton Melo 2		
	061-000-008	TH Barton Tibias		
	061-000-003	TH Big Pipes		
	061-000-004	TH Bold Brass		
	061-000-005	TH Full Brass		
	061-000-006	TH Melo 1		
	061-000-007	TH Melo 2		
	061-000-016	TH Mixed 1		
	061-000-017	TH Mixed 2		
	061-000-018	TH Mixed 3		
	061-000-019	TH Mixed 4		
	061-000-015	TH Morton Strings		
	061-000-010	TH Morton-StrVox-Wurl.		ExtID
	061-000-009	TH Morton-Str-Wurl.		
	061-000-011	TH Robert Morton		
	061-000-014	TH Wurl.Bx-Morton		
	061-000-013	TH Wurl.-Morton-Barton		
	061-000-012	TH Wurlizer-Morton		
	072-000-052	The Buzz		
	006-000-000	The Chorus		
	005-000-020	The Grand Piano		
	005-000-022	The Grand Piano		
	072-000-030	The Greek Pad		
	006-000-019	The Real Wersi		
	072-000-010	The Swarm		
	090-000-073	Theater Kinura		
	090-000-069	Theater Orgel		
	093-000-053	Theater Orgel + Chor		
	090-000-075	Theater Schlagzeug		
	090-000-070	Theater Streicher		
	093-000-054	Theater Streicher Sustain		
	090-000-068	Theater Tibia 8		ExtID

	006-000-091	Theatre Big Pipes		
	090-000-074	Theatre Diaphone		
	090-000-072	Theatre Sustain		
	083-000-050	Theremin		
	072-000-062	Thick Pulse Bass		
	081-000-073	Thin Air Pad		
	072-000-002	Thuer Bass		
	082-000-072	Thumb Bass		
	073-000-069	Thuy Stud Bass		
	009-000-107	Tibet Panflöte		
	009-000-108	Tibet Panflöte Art		
	073-000-109	Time For Flange		
	081-000-064	Tinker Bells		
	091-000-069	Tinkle Bell		
	072-000-020	Tinkling Wavetable Pad		
	083-000-089	Tite Room Funk Loop		
	072-000-120	Touchy Swe Pad		
	072-000-067	Trance Orchestra		
	073-000-065	Trance Worlds		
	083-000-067	Trancefloor Lead		
	073-000-114	Transistor Bass		
	073-000-042	Transistor Bass Line		
	073-000-079	Traveller		
	008-000-003	Tremolo Streicher 1		
	082-000-091	Tremolo Streicher 2		ExtID
	072-000-111	Triangle Arpeggio		
	073-000-116	TriStar Lead		
	009-000-060	Trompete 1		
	009-000-062	Trompete 1 Hell		
	009-000-061	Trompete 1 Weich		
	090-000-012	Trompete 2		
	091-000-119	Trompete 2 Echo		

	091-000-120	Trompete 2 Filter		
	090-000-054	Trompete 2 Scharf		
	060-000-029	Trompete 3		
	093-000-042	Trompete Alarm		
	082-000-035	Trompete Ente		
	090-000-055	Trompete Gestopft 1		
	082-000-036	Trompete Gestopft 2		
	091-000-074	Trompete Jazz		
	082-000-034	Trompete Klein		
	093-000-088	Trompete Live		
	009-000-063	Trompete Mariachi 1		ExtID
	093-000-087	Trompete Mariachi 2		
	093-000-041	Trompete PingPong		
	091-000-075	Trompete Solo 1		
	082-000-032	Trompete Solo 2		
	082-000-033	Trompete Solo 2 Weich		
	093-000-098	Trompete Solo 3		ExtID
	007-000-070	Trompete Vibrato		
	009-000-064	Trompeten Ensemble 1		
	090-000-106	Trompeten Ensemble 2		
	093-000-095	Trompeten Ensemble 3		
	009-000-089	TRP Ens. Shake After		
	009-000-084	TRP Ensemble Fall		
	009-000-085	TRP Ensemble Shake		
	009-000-088	TRP Ensemble Ups		
	009-000-087	TRP EnsembleModWheel		
	009-000-074	TRP-TRO Stack		
	084-000-003	Trumpet Acc		
	006-000-039	Trumpets Down!		
	091-000-027	Tuba 1		
	082-000-040	Tuba 2		
	006-000-012	Tubass		

	081-000-058	Tubular Bells		
	081-000-060	Tubular Bells Chimey		
	081-000-059	Tubular Bells Hart		
	060-000-031	Tutti 1		
	060-000-032	Tutti 2		
	060-000-033	Tutti 3		
	072-000-034	TV Mystery		
	093-000-016	Twilight		
	083-000-080	Ufo		
	073-000-118	UK Breakz Bass		
	081-000-025	Ultra Hard Vintage EP		
	072-000-012	Ultraog Bass		
	072-000-054	Ultraog Lead		
	072-000-007	Unison Bend Poly		
	073-000-108	Unitea Bass		
	083-000-026	Urban Pad		
	083-000-000	Vangelis Pad		
	006-000-044	Vatikan		
	072-000-087	Velo Perc Chordulator		
	073-000-031	Velo Perculator		ExtID
	082-000-083	Velo Stabs		
	073-000-105	Velocity BandBass		
	006-000-078	Veneziano		
	081-000-068	Viborbellz Cascade		
	090-000-001	Vibraphon 1		
	090-000-065	Vibraphon 2		
	007-000-053	Vibraphon Hell		
	081-000-050	Vibraphon Rich Stereo		
	093-000-056	Vibraphon Tremolo		
	081-000-049	Vibraphon Weich		
	006-000-101	Vibraphone		
	006-000-093	Vibrato Chor		

	006-000-061	Vienna Waltz		
	081-000-026	Vintage Amped EP		
	081-000-030	Vintage Road+Wurli		
	090-000-122	Viola / Bratsche		
	091-000-110	Violine + Streicher		
	090-000-008	Violine 1		
	090-000-101	Violine 2		
	091-000-116	Violine Solo		
	093-000-092	Violine Zigeuner		
	008-000-043	Virus Strings 1		
	008-000-044	Virus Strings 2		
	072-000-084	Vocality		
	073-000-032	Vocalizing		
	083-000-007	Vocalizing Pad		
	093-000-004	Vogel		
	083-000-082	Vogelstimmen		
	060-000-030	Voix Celeste		
	091-000-085	Vollenweider		
	090-000-126	Vorhören1		
	073-000-072	Vowelscapes		
	073-000-058	VS Bells		
	073-000-044	VS Choir Pad		
	083-000-051	Wannabe TB		
	073-000-040	Warm EE Piano		
	073-000-064	Warm Horn		
	006-000-025	Warm Hybrid Strings		
	091-000-046	Warm Pad		
	082-000-096	Warme Str. Fläche		
	073-000-048	Wave Line		
	072-000-078	Wave Pattern Pad		
	072-000-117	Wavebend Poly		
	073-000-041	Wavetable SweeperPad		

	072-000-037	Wavypan		
	082-000-086	Weiche Legato Streicher		
	082-000-090	WeicheHelle Lg.Streicher		
	082-000-087	WeicheStreicher VeloAtt.		
	072-000-036	Welcome		
	088-000-127	WERSI Effects		
	093-000-058	Western Gitarre 2		
	090-000-080	Western-Gitarre 1		
	081-000-063	Wheel Adjust Bell		
	006-000-013	Who the F*** is Axel		
	073-000-033	Wicked Square Arp		
	008-000-090	WindChimes		
	083-000-075	Windgeräusch		
	008-000-091	Woodblock		
	072-000-000	Worlds Apart		
	083-000-005	Worlds Apart Motion		
	072-000-017	Worlds Biggest Swe		
	083-000-028	Worried Dave Pad		
	081-000-029	Wurlitzer Weich		
	006-000-083	Xanadu Bells		
	006-000-035	Xmas Strings		
	007-000-052	Xylophon		
	090-000-056	Xylophon Holz		
	081-000-053	Xylophon Metall		
	081-000-054	Xylophone Oktave		
	083-000-079	Yeah Yeah Frog		
	006-000-068	Zirkus Renz		
	090-000-025	Zither 1		
	090-000-084	Zither 2		
	093-000-070	Zugriegel 16+1-1/3+1		
	093-000-068	Zugriegel 16+8+4+2		
	093-000-069	Zugriegel 16+8+4+2+1		ExtID

	093-000-071	Zugriegel Blues 1		
	093-000-072	Zugriegel Blues 2		
	093-000-073	Zugriegel Blues1+Perk.		
	093-000-074	Zugriegel Blues2+Perk.		
	093-000-066	Zugriegel Voll 1		
	093-000-067	Zugriegel Voll 2		

Device	MSB	LSB	PRG	Name0

Device	MSB	LSB	PRG	Name0
Device	MSB	LSB	PRG	Name0

