

# Index

- .wav files, 91
- 1-AIF WAVE, 91
- 1-SEQUENCE, 89, 91
- 1-SOUND, 89, 91
- 1-WAV WAVE, 91
- 8-VoiceChorus. *See* User's Guide
- A**
- AC power, 2
- Access disks utils?, 98
- Accessories
  - in box, 1
  - optional, 6
- Add, 61
- Adding memory, 104
- AIF, 49, 89
- AKAI S-1000 sounds
  - loading, 91
  - translation, 91
- AKAISND, 91
- All Notes Off button, 6
- All Notes Off, enabling reception, 97
- All Sounds Off, enabling reception, 97
- ALL-BYPASS, 46
- Allocating memory, 6
- ALL-SEQS, 89, 91
- ALL-SESSION, 89, 91
  - automatic loading of, 89
- ALL-SND, 8
- ALL-SOUNDS, 89, 91
- als, 89
- Alt Bus, 34, 42
- Alter system pitch?, 95
- Amp Env Attack, 16
- Amp Env Decay, 16
- Amp Env Release, 16
- Amp&Filt Env Vel, 17
- Analog synth sounds. *See* Stomper
- Append sequence?, 75
- Architecture overview, 4–6
- Arrow, downward-pointing, 87
- ASR-10 and ASR-88 sounds
  - loading, 91
  - translation, 91
- ASR-SND, 91
- ASR-X Pro User's Guide, 1
- Assignable controllers, setting up, 97
- Attack Level (1), 31
- Attack Time (1), 31
- Audio Inputs
  - using, 50
- Audio Outputs, 1
- Auto-locating, 58
- Automatic loading of settings, 89
- Auto-punching, 65
- AutoSelect FXBus, 94
- Auto-Step, 63
- Auto-Zero Cross, 95
- Aux Out jacks, 1
- Auxiliary outs
  - overview, 42
  - routing sounds to
    - from pads, 27
    - from tracks, 13
- AuxOut1-4, 13, 27, 42
- B**
- Bank Select Recv, 18
- Bank&ProgChgRecv, 97
- Banks, defined, 8
- Bypassing effects, 46
- BYPD, 46
- C**
- Categories. *See* SoundFinder
- CD-ROM drive, using. *See* SCSI
- Chaining sequences. *See* Pattern mode
- Change sound type?, 102
- Chatter Box. *See* User's Guide
- Chorus→Rev. *See* User's Guide
- Clearing RAM, 101
- Click, 66
  - adding an effect, 66
  - and time signatures, 64
  - choosing its sound, 66
  - saving settings to FLASH, 102
  - sending it to the Aux Outs, 66
  - setting its beat, 66
  - setting its loudness, 66
  - setting its panning, 66
  - turning on and off, 66
- Click Timing, 66
- ClockSource, 97
- Comp→Dist→DDL. *See* User's Guide
- Connecting SCSI cables, 85
- Controllers list, 118
- Controlling an external sequencer, 97
- Copy [disk name] disk?. *See*
- Copy sound?, 38
- Copy this sequence?, 75
- Copy track?, 72
- Copying a SCSI disk. *See*
- Copying tracks
  - (Destination) Seq, 74
  - Destination Track, 74
  - DestTime, 74
  - overview, 72
  - Paste
    - Append, 73
    - Merge, 73
    - Replace, 73
  - Scope, 73
- Countoff
  - choosing its sound, 66
  - setting its length, 67
  - setting when it occurs, 66
- Countoff, 66
- Countoff Bars, 67
- Countoff Sound, 66
- Create a new song?, 77
- Create new sequence?, 60
- Creating a New Sequence, 60
- CTRL1, CTRL2, CTRL3 and CTRL4, 97
- CTRL3 and Patch Select buttons, 98
- CUSTOM category
  - quick selection, 9
- Cut ModSrc, 33
- Cutoff ModAmt, 33
- D**
- Data Entry Recv, 18
- DDL→Chorus. *See* User's Guide
- DDL→EQ. *See* User's Guide
- DDL→Flanger. *See* User's Guide
- DDL→Phaser. *See* User's Guide
- Decay Time (4), 31
- Defragmenting. *See* Optimizing a SCSI disk
- Delay Offset, 15
- Delta quantizing, 69–70
- Demo, playing, 4
- DEMO-SND, 102
- Destination Track, 74
- DesfTime, 74, 75
- Device ID. *See* SCSI device IDs
- Directories. *See* Folders
- Directory Sorted, 101
- Disk storage
  - copying SCSI disks, 98
  - de-fragmenting SCSI disks, 99
  - erasing disk files, 100
  - Floppy
    - overview, 81
  - formatting disks, 98
  - free space on disk, 101
  - loading files
    - computer files with long names, 92
    - procedure, 90
    - selecting a file, 92
    - selecting a memory location, 92
    - types of files, 90
- overview of options, 81
- renaming disk files, 100
- resetting SCSI bus, 99
- saving files
  - naming files, 90
  - procedure, 88
  - types of files, 89
- SCSI
  - bus
    - defined, 82
    - resetting, 99
  - connecting cables, 85
  - device IDs
    - explained, 83
    - setting the ASR-X Pro's, 95
  - folders
    - creating new, 88
    - default, 85
    - explained, 85
    - invisible, 85
    - navigating, 87
  - overview, 82–85
  - powering up, 85
  - preparing for, 85
  - scanning SCSI bus, 87
  - termination
    - explained, 84
    - setting the ASR-X Pro's, 95
    - troubleshooting, 86
  - selecting device, 86–87
  - write-protecting SCSI disks, 100
- Disk utilities
  - checking free space, 101
  - copying SCSI disks, 98
  - de-fragmenting SCSI disks, 99
  - erasing disk files, 100
  - formatting disks, 98
  - renaming disk files, 100
  - resetting SCSI bus, 99
  - write-protecting a SCSI disk, 100
- Dist→Auto Wah. *See* User's Guide
- Dist→Chorus. *See* User's Guide
- Dist→DDL→Trem. *See* User's Guide
- Dist→Flanger. *See* User's Guide
- Dist→Phaser. *See* User's Guide
- Dist→VCF→DDL. *See* User's Guide
- Distortion curves in effects, 47
- Down arrow symbol, 87
- DpthModSrc, 34
- Drum mapping, 23, 113
- Dry, 13
- Dry, defined, 41
- E**
- Edit Click/Countoff?, 65
- Edit global reverb?, 43
- Edit insert effect?, 43
- Edit MIDI settings?, 96
- Editing
  - any parameter, 3
  - any value, 3
- EDM sounds, loading, 91
- efa, 91
- efe, 91
- Effect bus. *See* FX Bus
- Effects
  - adding to pad sounds
    - changing busses, 27
  - adding to track sounds
    - changing busses
      - from front panel, 13
      - via MIDI, 13
  - bypassing, 46
  - distortion curves, 47
  - editing, 43
  - LFO waveshapes, 47
  - overview, 41–42
    - global reverb, defined, 42
    - insert control track, 41
    - insert effects

- defined, 41
  - list, 41
- real-time modulation, 44
  - modulators list, 44
- selecting, 43
- setting the insert control track, 46
- Effects Edit button, 43, 46
- Effects Select button, 43
- Electro Static Discharge, 103
- ENSONIQ Drum Map, 113
- ENSONIQ Percussion Map, 113
- ENSONIQDISK, 87
- Enter button, 3
- Enter MemoryManager?, 101
- Enter pattern mode?, 76
- Env1PitchModAmt, 31
- Env2CutoffModAmt, 33
- Envelope Mode, 31
- EPS and EPS 16 PLUS sounds
  - loading, 91
  - translation, 91
- EQ→Chorus→DDL. *See* User's Guide
- EQ→Comp→Gate. *See* User's Guide
- EQ→Reverb. *See* User's Guide
- Erase all sequences?, 76
- Erase disk files?, 100
- Erase memory banks?, 101
- Erase sound?, 101
- Erase this sequence?, 76
- Erase track?, 74
- Erase trk to end?, 74
- Erasing ASR-X Pro RAM, 101
- Erasing tracks
  - a MIDI controller, 74
  - a note range, 74
  - all recorded data, 74
  - assorted data, 74
  - only within a region, 74
- ESD, 103
- ESP2, 41
- ESSENTIALS, 89
- Essentials buttons
  - assigning favorite sounds to, 9
  - default sound assignments, 9
  - in sound selection, 9
  - saving sound assignments to disk, 89
  - to FLASH, 102
- Exit button, 3
- EXP Expansion Boards, 6
- Exp Name, 102
- Expansion options, 103
- Expressn(11) Recv, 18
- EXP-SND, 8
- F**
- Fast-forwarding in a sequence, 58
- fav, 89
- FDX-100, 1
- Filt Env Attack, 16
- Filt Env Decay, 16
- Filt Env Release, 17
- Filter Cutoff, 16, 33
- Filter Resonance, 16
- Final Mix mode, 63
- FinderPref, 35
- Fine Tuning (global), 96
- Fine Tuning (sound), 30
- Fine Tuning (track), 14
- Flanger →Rev. *See* User's Guide
- FLASH
  - saving settings to, 102
- FLASH, defined, 6
- Floppy disk
  - selecting for use, 86
- Floppy disks
  - advantages/disadvantages, 81
  - formatting, 98
  - inserting in drive, 82
  - removing from drive, 82
  - write-protection, 81
- Folders
  - creating new
    - using ASR-X Pro, 88
    - using computer, 88
  - explained, 85
    - invisible folders, 85
  - navigation, 87
    - where disk files are saved, 89
- Foot switch
  - assigning functions, 93
  - connecting, 2
- FootPedal(4) Recv, 18
- Formant Morph. *See* User's Guide
- Format disk?. *See* Free, 101
- Free, 101
- Free space
  - in RAM, 101
  - on disk, 101
- From= parameter, 65
- FtSw L and FtSw R, 93
- FX Bus
  - defined, 42
  - pad parameter, 27
  - track parameter, 13
- FX Bus (click), 66
- G**
- Gate Percentage, 63
- Gate Time, 62
- Gated Reverb. *See* User's Guide
- Glide Mode, 15, 30
  - changing via MIDI, 15
- Glide Time, 15, 30
- Global pitch bend, 95
- Global pitch table, 96
- Global reverb
  - defined, 42
  - editing, 43
  - Light, Medium, Wet, 42
  - list, 42
  - selecting, 43
- Global Reverb=, 43
- GM Kit Map, 114
- Group solo, 19
- Guitar Amp. *See* User's Guide
- H**
- Hall Reverb. *See* User's Guide
- Hard disk. *See* SCSI
- Held pitch bend, 96
- Hex wrench, 103
- I**
- In Bus, 51
- Index ModAmt, 29
- IndxModSrc, 29
- Input Level knob, 50
- Insert, 13
- Insert control track
  - defined, 41
  - setting, 46
- Insert effect parameters. *See* User's Guide
- Insert Effect=, 43
- Insert effects
  - adding to pad sounds, 27
  - adding to track sounds, 13
  - defined, 41
  - editing, 43
  - in song mode, 77
  - list, 41
  - real-time modulation, 44
    - modulators list, 44
  - selecting, 43
- Insert FX Bus
  - GlobalReverb Amt, 44
  - Input Mix, 44
- Insert: Mod Dest, 45
- Insert: Mod Dest Min and Max, 45
- Insert: Mod Src, 45
- Insert: Mod Src Min and Max, 45
- Installing
  - additional sample memory, 104–6
  - an EXP wave expansion board, 106–8
- Installing expansion options, 103
- Invert sample data?, 37
- Invisible folders. *See* Folders
- K**
- Key Group Assign, 35
- Key Range Hi, 17
- Key Range Lo, 17
- Keybd TimeScaling, 32
- Keybd Track, 33
- KeybdTrack, 30
- Kit Mapper, 23
- Knobs
  - Parameter and Value, 3
  - Sound Type and Sound Name, 3
- L**
- Large Plate. *See* User's Guide
- Large Room. *See* User's Guide
- Layers, in sounds, 22
- LEDs
  - flashing
    - Exit/No and Enter/Yes, 3
    - Mute/Solo, 19
  - Play and Record buttons, 59
  - Sampling Level, 50
- LFO Delay Time, 16, 34
- LFO Depth, 16, 34
- LFO Key Restart, 35
- LFO Pitch ModAmt, 30
- LFO Rate, 34
- LFO Rate ModAmt, 34
- LFO Shape, 34
- LFO Start Phase, 34
- LFO Sync, 35
- LFODepth ModAmt, 34
- LFOs in effects, 47
- LightReverb, 13
- LightReverb FX Bus, 44
- Lights. *See* LEDs
- Link, 32
- Load button, 90
- Load from disk?, 90
- Loading .wav files, 91
- Local Off Channel, 96
- Locating within a sequence, 58
- Location in sequence, 59
- Loop End, 29
- Loop Playback, 64
- Loop Start, 29
- Looping waves, 29, 95
- Low Key/High Key, 71
- M**
- Main Out jacks, 1
- Make a RAM kit from...?, 24
- Making a new sequence, 60
- Maximum number of notes, 6
- MediumReverb, 13
- MediumReverb FX Bus, 44
- Memory. *See* Sample memory
- Memory Manager, 101
  - Change sound type?, 102
  - Erase memory banks?, 101
  - Erase sound?, 101
  - EXP Name, 102
  - Show free memory?, 101
- Method, 69
- Metronome. *See* Click
- mfb, 89
- Mic/Line switch, 50
- mid, 89
- Middle C, 17
- MIDI
  - All Notes Off, 97
  - All Sounds Off, 97
  - ASR-X Pro note range, 21
  - Bank Selects
    - numbers, 8, 10
  - changing FX bus, 13
  - changing Glide Mode, 15
  - channels, described, 116
  - controllers
    - list, 118
    - reception behavior, 120

- editing track parameters, 12
  - enabling track reception
    - of Bank Selects, 18
    - of CTRL1-4 messages, 18
    - of Data Entry messages, 18
    - of Expression messages, 18
    - of Foot Pedal messages, 18
    - of Mod Wheel messages, 18
    - of Pan messages, 18
    - of Pitch Bend messages, 18
    - of Program Changes, 18
    - of Sustain/Sostenuto messages, 18
    - of Volume messages, 18
  - enabling transmission of data, 13
  - hardware, 116
  - implementation, 119
  - implementation chart, 119
  - jacks, 2
  - Local-off operation, 96
  - muting tracks, 19
  - note names/numbers, 21
  - playing sounds from, 10
  - Program Changes
    - numbers, 8, 10
  - recording to external sequencer, 96
  - Reset All Controllers, 97, 120
  - selecting sounds, 10
  - Song Position Pointer
    - receiving and transmitting, 97
  - synchronizing to external sequencer, 97
  - Tuning Standard
    - further info, 124
    - using, 124
  - using RPNs and NRPNs, 122
  - MIDI-OUT sounds
    - programming and using, 10
  - Mix (Expression), 12
  - Mixdown, 63
  - Mod Wheel(1) Recv, 18
  - Mode, 32
  - Modulators
    - sound modulators list, 27
  - Mono, using the ASR-X Pro in, 1
  - Move Note Offs, 72
  - Multiple ASR-X Pros, using, 97
  - Multi-Tap DDL. *See* User's Guide
  - Multi-timbral, defined, 116
  - mute, 19
  - Mute/Solo button, 19
  - Muting a track
    - using Mute/Solo button, 19
    - via MIDI, 19
- N**
- No button, 3
  - Noise Sync, 35
  - NoiseSourceRate, 35
  - NonLinReverb1. *See* User's Guide
  - NonLinReverb2. *See* User's Guide
  - Non-Registered Parameters. *See* NRPNs
  - Normal LFO Rates, 15
  - Normalize gain?, 36
  - Normalizing, defined, 51
  - NRPNs
    - defined, 122
    - list, 123
    - using, 123
- O**
- Octave Shift, 14
  - Octave Transpose buttons
    - using, 23
    - what they do, 23
    - when sending to pads, 54
  - Offset, defined, 11
  - On switch, 2
  - Opening the ASR-X Pro, 103
  - Operating system
    - defined, 108
    - upgrading, 108-9
    - What version am I using?, 108
    - What's the most recent version?, 108
  - Optimize [disk name] disk?, 99
  - Optimizing a SCSI disk, 99
  - OS. *See* Operating system
  - Outputs, 1
  - Override, defined, 11
- P**
- Pad Edit button, 25
  - Pad Pan, 26
  - Pad Process button, 36
  - Pad Sound button, 25
  - Pad Volume, 26
  - Pad Xpose, 23
  - Pads
    - editing, 24
      - PAD parameters, 26
    - editing pad sounds, 27
      - AMP parameters, 33
      - ENV1 parameters, 31
      - ENV2 parameters, 33
      - ENV3 parameters, 34
      - FILT parameters, 32
      - FLT1 & FLT2 parameters, 33
      - MISC parameters, 35
      - MOD parameters, 34
      - modulators, 27
      - PITCH parameters, 30
      - WAVE parameters, 29
    - processing waves
      - copying waves, 38
      - inverting data, 37
      - normalizing, 36
      - overview, 36
      - reducing sample bits, 37
      - time-scaling waves, 38
      - truncating, 38
      - volume scaling, 36
    - selecting sounds, 25
    - what pads play, 21
      - a whole kit at once, 23
      - resetting, 23
  - Pads Play Local, 96
  - Pan (click), 66
  - Pan ModAmt, 33
  - Pan ModSrc, 33
  - Pan(10) Recv, 18
  - Parameter knob, 3
  - Parameter, defined, 3
  - Parameters
    - editing track parameters, 11
  - Parametric EQ. *See* User's Guide
  - Paste, 73
  - Patch Select buttons
    - and CTRL3, 98
    - and MIDI, 24
    - as modulation devices, 98
    - modes
      - Live or Held, 93
      - what they do, 23
  - Patch Selects, 93
  - Pattern mode. *See* Pattern mode
  - Patterns. *See* Pattern mode
  - Pedals. *See* Foot switch
  - Percussion mapping, 113
  - Phaser →Rev. *See* User's Guide
  - Phones jack, 1
  - Pitch Bend Down, 30
  - Pitch Bend Recv, 18
  - Pitch Bend Up, 30
  - Pitch Bend Up, Pitch Bend Down (global), 95
  - Pitch Bend Up, Pitch Bend Down (track), 14
  - Pitch bend wheel, described, 95
  - Pitch Detuner. *See* User's Guide
  - Pitch ModAmt, 30
  - Pitch ModRange, 30
  - Pitch tables
    - creating, 124
    - list, 124
  - PitchBendMode, 30, 96
  - PitchTbl (global), 96
  - PitchTbl (sound), 30
  - PitchTbl (track), 14
  - Play/Top button, 58
  - Playing a sequence, 58
  - Playing the ASR-X Pro Demo, 4
  - PlayMode, 29
  - Polyphony, 6
  - Powering up ASR-X Pro, 2
    - when using SCSI, 85
  - ppqn, 59
  - Pre-quantization, 65
  - PressureMode, 17
  - Pre-Trigger, 52
  - PROC, 36
  - Prog, 12, 13, 27, 42
  - ProgramChngeRecv, 18
  - Protecting a SCSI disk, 100
  - PtchModSrc, 30
  - Punching in
    - manually, 58
    - with a foot switch, 94
- Q**
- Q, 32
  - Quantize To, 68
  - Quantize track?, 67
  - QuantizeNoteOffs, 72
  - Quantizing tracks
    - adding randomness, 71
    - adding swing, 70
    - as you record, 65
    - in a specific key range, 71
    - method
      - Normal or Delta, 69
    - moving the ends of notes, 72
    - overview, 67
    - setting the quantization value, 68
    - setting the strength, 70
    - setting which notes are quantized, 71
    - shifting the whole track, 71
    - templates
      - described, 68
      - list of templates, 115
      - saving your own, 72
      - to FLASH, 102
    - the lengths of notes, 72
- R**
- RAM kit
    - defined, 24
    - how it's named, 25
    - where it goes, 24
  - RAM pitch table, 124
  - RAM, defined, 5
  - Ramp Level (2), 31
  - Ramp Level (3), 31
  - Ramp Time (2), 31
  - Ramp Time (3), 31
  - RAM-SND, 8
  - Random, 71
  - Rate ModSrc, 34
  - Real-time modulation, 44
  - Rec Mode (sampling/resampling), 51
  - Record Mode, 61
  - Record Time, 51
  - Record/Scoop button, 58
  - Recording. *See* Sequencing
  - RecordQuantize, 65
  - Reduce sample bits?, 37
  - Region FromPoint, 65
  - Region ToPoint, 65
  - Regions
    - defined, 64
    - end
      - To=, 65
      - ToPoint, 65
    - start
      - From=, 65
      - FromPoint, 65
  - Registered Parameters. *See* RPNs
  - Release Time (5), 32
  - Removable drive. *See* SCSI
  - Rename disk files?, 100
  - Rename sequence?, 75
  - Rename Sound?, 35, 101
  - Renaming a sound, 101
  - Replace, 61

- Resampling. *See* Sampling/Resampling
  - Resampling Setup button, 50
  - Reset All Controllers
    - enabling reception, 97
    - reception behavior, 120
  - Reset SCSI bus?, 100
  - ResetControlRecv, 97
  - Resolution of sequencer, 59
  - Resonance (Q), 32
  - ResVCF→DDL. *See* User's Guide
  - Retro synth sounds. *See* Stomper
  - Rev→Chorus. *See* User's Guide
  - Rev→Flanger. *See* User's Guide
  - Rev→Phaser. *See* User's Guide
  - Reverb. *See* Global reverb
    - adding to pad sound, 27
    - adding to track sound, 13
  - Reverb Return Level, 44
  - Rewinding to the beginning of a sequence, 58
  - Roland S-770 sounds
    - loading, 91
    - translation, 91
  - Roll Breakpoint, 33
  - Roll Slope, 33
  - Rolloff Mode, 33
  - ROM Pitch Tables list, 124
  - ROM sounds list. *See* User's Guide
  - ROM waves list, 111
  - ROM, defined, 5
  - ROM-SND, 8
  - RotarySpeaker. *See* User's Guide
  - RPNs
    - defined, 122
    - using, 122
- S**
- Sample memory
    - as shipped from factory, 104
    - expansion options for the ASR-X Pro, 104
  - Sample Start, 29
  - Sample, defined, 49
  - Samples. *See* Waves
  - Sampling In Progress, 53
  - Sampling Level LEDs, 50
  - Sampling/Resampling
    - available sampling time, 104
    - building your own kit, 54
    - how sounds are named, 54
    - making a sample, 53
    - overview
      - Audio Inputs, 50
      - audio sources, 49
      - resampling, defined, 49
      - sampling, defined, 49
      - Scratch Pad, 49
      - wave, defined, 49
    - sending to pads
      - explained, 54–55
      - process, 53–54
    - setting up, 50–52
      - automatic normalization, 51
      - saving setup to FLASH, 102
      - selecting a source, 50
      - selecting an effect bus, 51
      - setting sampling time, 51
      - setting the pre-trigger time, 52
      - setting the trigger level, 52
      - setting the trigger mode, 52
      - stereo or mono?, 51
    - where sounds go, 54
  - Save button, 89
  - Save quantize as?, 72
  - Save these settings?, 102
  - Save to disk?, 89
  - Saving your own quantizing template, 72
  - sbx, 89
  - Scale loudness?, 36
  - Scale time?, 38
  - Scan SCSI devices?, 87
  - Scoop, 58
  - Scope, 73
  - Scratch Pad
    - described, 49
    - playing, 53
    - saving contents to disk, 90
    - when it's erased, 54
  - SCSI
    - advantages/disadvantages, 81
    - bus
      - explained, 82
      - not functioning, 99
      - terminating correctly, 84, 95
      - unscrambling, 99
      - using proper device IDs, 83, 95
    - cables
      - connecting, 85
    - device Ids
      - explained, 83
      - setting the ASR-X Pro's, 95
    - disk
      - selecting for use, 86
      - scanning SCSI bus, 87
    - disks
      - formatting, 98
    - folders
      - creating new
        - using ASR-X Pro, 88
        - using computer, 88
      - explained, 85
        - default, 85
        - invisible, 85
      - navigating, 87
    - powering up system, 85
    - preparing for, 85
    - termination
      - explained. *See* setting the ASR-X Pro's. *See*
    - troubleshooting, 86
    - utilities
      - disk copying, 98
      - disk formatting, 98
      - disk optimization, 99
      - re-setting SCSI bus, 99
      - write-Protection, 100
    - What is SCSI?, 82
  - SCSI Device ID, 95
  - SCSI II. *See* SCSI
  - SCSI Termination, 95
  - Select Device?, 87
  - Select Track buttons, 7
  - Selecting Sequences, 60
  - Semitone Shift, 14
  - SemitoneTuning, 30
  - Send to Pads button, 54
  - Sending to pads, 53–55
  - Seq parameter, 74
  - Sequence banks, 89, 91
  - Sequence Edit button, 60
  - Sequence length, 64
  - Sequence names, 75
  - Sequence Process button, 67
  - Sequence Select button, 59
  - Sequencing
    - chaining sequences, 76
    - changing time signatures, 64
    - creating a new sequence, 60
    - creating songs, 77–78
    - looping a sequence, 64
    - metronome click and countoff, 65–67
    - operating the transport controls, 58
    - overview, 57–58
    - playing part of a sequence, 65
    - processing
      - part of a track, 65
    - processing sequences
      - appending, 75
      - copying, 75
      - erasing all sequences, 76
      - erasing current sequence, 76
      - overview, 67
      - renaming, 75
    - processing tracks
      - copying, 72–74
      - erasing, 74
      - overview, 67
      - quantizing, 67–72
      - undoing, 67
    - quantizing as you record, 65
    - recording fade-outs, etc., 63
    - recording from MIDI, 79
      - undoing tracks, 79
    - recording modes, 61
    - recording tempo changes, 63
    - recording track parameter changes, 63
    - resolution, 59
    - selecting a sequence, 60
    - setting tempo
      - by tapping, 60
      - with parameter, 60
    - step recording, 61
    - using regions, 64
  - Sequencing overview
    - What's a sequence?, 58
    - What's a sequencer?, 57
  - Set system prefs?, 93
  - Shift, 71
  - Show free memory?, 101
  - Shrinking samples. *See* Scale time?
  - SIMM chips
    - installation procedure, 104–6
    - overview, 105
    - requirements, 105
  - Small Plate. *See* User's Guide
  - Small Room. *See* User's Guide
  - SMDI, 86
  - SMF, 89
  - SND, 91
  - solo, 19
  - Soloing a track
    - using Mute/Solo button, 19
  - Song mode, 77
    - creating a song, 77
    - editing a song, 77–78
    - exiting, 77
    - playing a song, 77
  - Song Position Pointer
    - transmission and reception, 97
  - sou, 89
  - Sound Name knob, 3
  - Sound Type knob, 3
  - SoundFinder, 8, 35
    - changing a sound's type; sound is assigned. Press the Yes button is response to, 102
    - list of sound types, 112
  - SoundFinder parameter, 102
  - Sounds
    - changing SoundFinder type, 102
      - USER-SND and DEMO-SND, 102
    - erasing all sounds, 101
    - erasing from a pad
      - shortcut, 25
    - erasing from a track
      - shortcut, 11
      - using the Memory Manager, 101
    - listing of ROM sounds. *See* User's Guide
    - renaming a sound, 101
    - selecting
      - for a pad, 25
      - for a track
        - via MIDI, 10
    - selecting for a track
      - from front panel, 8–9
    - structures
      - illustration, 22
      - kit sounds, defined, 22
      - standard sounds, defined, 22
    - types, 8
      - list, 112
  - Source, 50
  - spb, 89
  - Spinner→Rev. *See* User's Guide
  - ssx, 89
  - Standard MIDI File, 89
  - Standard sounds, 22
  - Start demo playback?, 4
  - Start/Loop, 29
  - Start/Stop button, 53

- StartToEndIndex, 29
- Static warning, 103
- Step recording, 61
  - chords, 63
  - overview, 61
- Step Size, 62
- Stereo
  - panning a pad sound, 26
  - panning a track sound, 13
- Stereo Chorus. *See* User's Guide
- Stomp!, 39
- Stomper, 39–40
- Stop/Locate button, 58
- Stopping a sequence, 58
- Storage device selection, 86
- Strength, 70
- Stretching samples. *See* Scale time?
- Sustain Level (4), 32
- Sustain Pedal, 35
- Sustain/SostRecv, 18
- SW-10 foot switch, 6
- SW-2 foot switch, 6
- SW-6 foot switch, 6
- Swing, 70
- SyEx Device ID, 97
- Synchronizing
  - effects, 97
  - LFOs and noise generators, 97
  - to external sequencer, 97
- SyncLFO&Noise, 15
- Synthesize sound?, 39
- Synthesize Stomper sound?, 39
- SysCTRL1-4 Recv, 18
- SysCtrls
  - setup, 97
- SyEx data on SMF tracks, 89
- System pitch bend, 95
- System pitch table, 96
- System/MIDI button, 92
- System/MIDI parameters
  - overview, 92
- SYSTEMSETUP, 89, 91
  - automatic loading of, 89
- T**
- Template, 68
- Templates list, 115
- Termination. *See* SCSI Termination
- Threshold, defined, 52
- Time, 62
- Time compression/stretching. *See* Scale time?
- Time Signature, 64
- Timing correction. *See* Quantizing tracks
- TK symbol, 7
- To= parameter, 65
- Touch Curve, 93
- Track Edit/Mix/FX Bus button, 11
- Track Mix mode, 63
- Track Pan, 13
- Track ParamReset, 95
- Track ParamReset Behavior, 121
- Track Sound button, 7
- Track Undo, 67
- Track Volume, 12
- TrackBreakpoint, 33
- TrackMIDIOut, 13
- Tracks
  - introduction, 7
  - parameters
    - editing, 11
    - resetting, 8
  - selecting, 7
- Tracks
  - and Track Param Reset, 121
  - and Track ParamReset, 95
  - parameters
    - recording changes, 63
    - resetting, 121
    - selecting sounds, 8–11
- Transfers via SMDI, 86
- Transport buttons, 58
- Trig Mode, 52
- Trigger, 52
- Truncate length?, 38
- Tunable Spkr. *See* User's Guide
- Tuning Shift, 27
- Tuning Tables
  - creating, 124
- Turning click on or off, 66
- Turning on ASR-X Pro, 2
- U**
- Undo track ?, 67
- USER TEMP, 72
- USER-SND, 102
  - quick selection, 9
- Using RPNs, NRPNs to Edit Parameters, 122
- V**
- Value knob, 3
- Value, defined, 3
- Vel Curve, 32
- Vel Levels ModAmt, 32
- VelAtckTimeModAmt, 32
- Velocity Mode, 17
- VelocityRange Hi, 17
- VelocityRange Lo, 17
- VelRelTimModAmt, 32
- Voice Mode, 30
- Vol ModSrc, 33
- Vol/MixPolarity, 13
- Volume, 2
  - of a pad, 26
  - of a track, 12
- Volume (click), 66
- Volume knob, 2
- Volume ModAmt, 33
- Volume(7) Recv, 18
- W**
- Waiting For Trigger., 53
- wav files, 91
- Wave expansion board
  - installation procedure, 106–8
  - name, 102
- Waves
  - copying, 38
  - defined, 49
  - inverting, 37
  - list of built-in, 111
  - normalizing
    - automatically, 51
    - manually, 36
  - playing a wave on all pads, 55
  - processing, 36–39
  - reducing sample bits, 37
  - scaling loudness, 36
  - time-scaling, 38
  - truncating, 38
- WetReverb, 13
- WetReverb FX Bus, 44
- What can be sampled?, 49
- What Is MIDI?, 115
- Where did my track settings go?, 8
- Why do I only hear a few drum sounds?, 23
- Why don't the pads do anything?, 96
- Why is my edit doing nothing?, 12
- Why won't my SCSI drive work?, 86
- Window Minimum and Maximum, 71
- World Wide Web, 1
- Wrench, 103
- Writable disks, explained, 82
- Write-Protect, 100
- X**
- X-8 output expander, 6
- X-Audio audio CDs, 6
- XMit MIDI Clocks, 97
- Y**
- Yes button, 3