Table of Contents

1 Welcome 1

The ASR-X Pro Experience Begins....1
What Else is in the Box?....1
Setting Up the ASR-X Pro....1
Using the Audio Outputs....1
Setting the Output Volume....2
The Audio Inputs....2
Making MIDI Connections....2
Using a Foot Switch with the ASR-X Pro....2
Powering the ASR-X Pro....2
The ASR-X Pro Controls....3
The ASR-X Pro Display....3
The Knobs....3
The Exit/No and Enter/Yes Buttons and Their LEDs....3
Playing the Demo....4
Important ASR-X Pro Concepts....4
Architecture Overview....4
You Are Here....5
What's Where....5
The All Notes Off Button....6
About Note, Tips and Warnings in the ASR-X Pro Documentation....6
Optional Accessories for the ASR-X Pro....6

2 Tracks 7

Introduction to Tracks....7
To Select One of the Tracks in the Currently Selected Sequence....7
Selecting a Sound for a Track....7
Banks and Sounds....8
Selecting a Track's Sound Using the Sound Type and Sound Name Knobs....8
SoundFinder....8
Selecting a Track's Sound Using the Essentials Buttons....9
Programming the Essentials Buttons....9
Selecting and Playing a Track's Sound Via MIDI....10
Selecting and Programming a MIDI-OUT Sound....10
Quickly Erasing a Track Sound....11
Editing Track Parameters....11
Overrides and Offsets....11
Editing Track Parameters Via MIDI....12
What Each Track Parameter Does....12
Muting and Soloing a Track....19
Muting and Soloing from the Front Panel....19
Muting Tracks via MIDI....19

3 Pads 21

The Pads:Overview....21
What are the Pads?....21
What the Pads Play....22
Standard Sounds....22
Kit Sounds....22
Octave Transpose Buttons....23
The Kit Mapper....23
Patch Select Buttons....23
Patch Selects and MIDI....24

Programming the Pads 24
Overview 24
To Prepare the Selected Track's Sound for Pad Editing 24
Selecting a Pad for Editing 25
Choosing a Pad's Sound 25
Overview of the Pad Edit Parameters 25
Determining a Pad's Behavior 26
PAD Parameters 26
Editing a Pad's Sound 27
The ASR-X Pro Modulators 27
WAVE Parameters 29
PTCH Parameters 30
ENV1 Parameters 31
FILT Parameters 32
FLT1 and FILT2 Parameters 33
ENV2 Parameters 33
AMP Parameters 33
ENV3 Parameters 34
MOD Parameters 34
MISC Parameters 35
Processing a Sound's Wave 36
The Pad Process Display 36
The Pad Processes 36
Normalize gain? 36
Scale loudness? 36
Reduce sample bits? 37
Invert sample data? 37
Truncate length? 38
Copy sound? 38
Scale time? 38
Stomp! 39
Sound Type 39
Oscillator # 39
Mode 39
Oscillator Mode Stomper Parameters 40
Filter Mode Stomper Parameters 40

4 Effects 41

Overview of the ASR-X Pro Effects 41
Insert Effects 41
The Insert Control Track 41
Global Reverb 42
FX Busses: How Sounds are Sent to the Effects 42
Selecting and Editing a Sequence's Effects 43
To Select an Effect 43
To Edit an Effect 43
Insert Effect and Global Reverb Context Parameters 44
Insert Effect Real-Time Modulation Parameters 44
Setting a Sequence's Insert Control Track 46
Bypassing a Sequence's Effects 46
LFO Wave Shapes 47
Distortion Curves 47

5 Sampling/Resampling 49

Overview 49
What is Sampling? 49
What is Resampling? 49
What Happens When You Create a Wave 49
What can be Sampled in the ASR-X Pro 49
Using the ASR-X Pro Audio Inputs 50

Resampling Setup 50
Source 50
In Bus 51
Recording Mode 51
Auto-Normalize 51
Record Time 51
Pre-Trigger Time 52
Trig Mode 52
Setting the Trigger Threshold 52
Sampling/Resampling a Wave 53
How to Start and Stop Sampling a Wave 53
Sending a Wave to Pads 53
What Happens When You Send a Wave to a Pad or Pads? 54
Automatically Spreading a Wave Across all of a Kit's Pads 55

6 Sequencing 57

Overview 57
How the ASR-X Pro Sequencer Works 57
What is a Sequence? 57
Operating the Sequencer 58
The Sequence Select Button 59
Creating a New Sequence 60
Selecting Sequences 60
The Sequence Edit Button 60
Tempo 60
RecordMode 61
Step Recording 61
Recording Track Parameter Changes 63
Recording Sequence Volume and Tempo Changes 63
Loop Playback 64
Time Signature 64
Using Regions 64
RecordQuantize 65
Edit Click/Countoff? 65
The Sequence Process Button 67
Undo track ? 67
Quantize track? 67
Copy track? 72
Erase track? 74
Erase trk to end? 74
Rename sequence? 75
Append sequence? 75
Copy this sequence? 75
Erase this sequence? 76
Erase all sequences? 76
Enter pattern mode? 76
Create a new song? 77
Playing a Song 77
Exiting and Re-Entering Song Mode 77
Editing a Song 77
Adding a Step to the End of a Song 78
Inserting and Erasing Song Steps 78
The ASR-X Pro Sequencer and MIDI 79

7 Disk/Global 81

The Disk/Global Controls 81
Storage Options 81
Introduction to Floppy Disk Storage 81
The Floppy Disk Drive 81
Introduction to SCSI Storage 82
What is SCSI? 82

About SCSI Device IDs 83
About Termination 84
Folders/Directories 85
Invisible Folders 85
Preparing for SCSI 85
Attaching SCSI Cables 85
Powering Up SCSI Devices 85
Troubleshooting Your SCSI System 86
SMDI Transfers 86
The Disk Buttons 86
SCSI Device Selection and Navigation 86
Select Device? 87
Scan SCSI Devices? 87
Folder Navigation 87
Creating a New Folder Using the ASR-X Pro 88
Creating a New Folder Using a Computer 88
The Save Button 88
File Types that can be Saved 89
Saving the Contents of the Scratch Pad to Disk 90
Naming Disk Files 90
The Load Button 90
File Types that can be Loaded 90
A Note About Imported ASR-10 and ASR-88 Sounds 91
Selecting an Individual File to be Loaded 92
Selecting a Location into which a Sound will be Loaded 92
The System/MIDI Button 92
Set system prefs? 93
Touch Curve 93
Patch Selects 93
FtSw L and FtSw R (..... 93
AutoSelect FXBus 94
Track ParamReset 95
Auto-Zero Cross 95
SCSI Device ID 95
SCSI Termination 95
Alter system pitch? 95
The System Pitch Bend Setup 95
Fine Tuning 96
PitchTbl 96
Edit MIDI settings? 96
Local-Off Operation of the ASR-X Pro 96
ClockSource 97
Xmit MIDI Clocks 97
Bank&ProgChgRecv 97
ResetControlRecv 97
AllNotesOff Recv 97
SysEx Device ID 97
CTRL1, CTRL2, CTRL3 and CTRL4 97
Access disks utils? 98
Format disk? 98
Copy [disk name] disk? 98
Optimize [disk name] disk?" 99
A Note About the SCSI Copy and Optimize Utilities 99
Reset SCSI bus? 99
Write-Protect 100
Erase disk files? 100
Rename disk files? 100
Directory Sorted 101
Free 101

Enter MemoryManager?....101
Show free memory?....101
Erase memory banks?....101
Erase sound?....101
Rename sound?....101
Change sound type?....102
Exp Name....102
Save these settings?....102

8 Expanding the ASR-X Pro 103

Overview....103
An Important Note About Electro Static Discharge....103
Opening the ASR-X Pro....103
Installing Additional Sampling/Resampling Memory....104
Installing an ENSONIQ EXP-Series Wave Expansion Board....106
Updating the ASR-X Pro Operating System....108

9 Supplemental Information 111

List of ROM Waves....111
List of SoundFinder Categories....112
Drum and Percussion Maps....113
ENSONIQ Drum Map....113
ENSONIQ Percussion Map....113
GM Kit Map....114
List of Quantize Templates....115
What Is MIDI?....115
Life In The MIDI World....115
Understanding MIDI....116
MIDI Hardware....116
How MIDI Channels Work....116
How MIDI Messages Work....117
The Art of MIDI....117
List of MIDI Controller Names....118
ASR-X Pro MIDI Implementation....119
MIDI Implementation Chart....119
MIDI Controllers Reception Behavior....120
Reset All Controllers Reception Behavior....120
Track ParamReset Behavior....121
Using RPNs and NRPNs to Edit Parameters....122
Registered Parameters....122
Non-Registered Parameters....123
List of NRPNs....123
Pitch Tables and the MIDI Tuning Standard Format....124
List of ROM Pitch Tables....124

Index 127